



KOHLER® KD 625/2



KOHLER
ENGINES

REGISTRATION OF MODIFICATIONS TO THE DOCUMENT

Any modifications to this document must be registered by the drafting body, by completing the following table.

Drafting body	Document code	Model N°	Edition	Revision	Issue date	Review date	Endorsed
CUSE/ATLO 	ED0053029380	51266	1°	0	06/07/2012	06/07/2012	



KD 625/2

PREFACE

- Every attempt has been made to present within this service manual, accurate and up to date technical information. However, development on the **KOHLER** series is continuous. Therefore, the information within this manual is subject to change without notice and without obligation. The materials used by **KOHLER** to construct the engine's components undergo strict quality controls and the engine's assembly guarantees reliability and long life. The engine has been built to the machine manufacturer's specifications, and it was its responsibility to adopt all the measures needed to meet the essential health and safety requirements as provided for by the laws in force; use of the engine for uses other than the one defined shall not be considered as compliant with the use intended by **KOHLER**, who therefore refuses all responsibility for any injury arising from such an operation.
- The information contained within this service manual is the sole property of **KOHLER**. As such, no reproduction or replication in whole or part is allowed without the express written permission of **KOHLER**.

Information presented within this manual assumes the following:

- 1 - The person or people performing service work on **KOHLER** series engines is properly trained and equipped to safely and professionally perform the subject operation;
 - 2 - The person or people performing service work on **KOHLER** series engines possesses adequate hand and **KOHLER** special tools to safely and professionally perform the subject service operation;
 - 3 - The person or people performing service work on **KOHLER** series engines has read the pertinent information regarding the subject service operations and fully understands the operation at hand.
- This manual was written by the manufacturer to provide technical and operating information to authorised **KOHLER** after-sales service centres to carry out assembly, disassembly, overhauling, replacement and tuning operations.
 - As well as employing good operating techniques and observing the right timing for operations, operators must read the information very carefully and comply with it scrupulously.
 - Time spent reading this information will help to prevent health and safety risks and financial damage. Written information is accompanied by illustrations in order to facilitate your understanding of every step of the operating phases.

**CALIFORNIA EMISSION CONTROL WARRANTY STATEMENT
YOUR WARRANTY RIGHTS AND OBLIGATIONS**

The California Air Resources Board and Kohler Co. are pleased to explain the **emission control system warranty** on your 2012 engine. In California, new heavy-duty off-road engines must be designed, built and equipped to meet the State's stringent anti-smog standards. Kohler Co. must warrant the emission control system on your engine for the time period listed below provided there has been no abuse, neglect or improper maintenance of your engine.

Your emission control system may include parts such as the fuel-injection system and the air induction system. Also included may be hoses, connectors and other emission related assemblies.

Where a warrantable condition exists, Kohler Co. will repair your heavy-duty off-road engine at no cost to you including diagnosis, parts and labor.

MANUFACTURER'S WARRANTY COVERAGE:

Your off-road, diesel engine emission control system is covered under warranty for a period of five (5) years or 3,000 hours, whichever occurs first, beginning on the date the engine or equipment is delivered to an ultimate purchaser for all constant speed engines with maximum power $19 \leq kW < 37$ and rated speed less than 3,000 rpm, all variable speed engines with maximum power $19 \leq kW < 37$, and all variable or constant speed engines with maximum power greater than 37 kW. Your off-road, diesel engine emission control system on variable or constant-speed engines with maximum power less than 19 kW, and for constant speed engines with maximum power $19 \leq kW < 37$ and rated speed equal to or greater than 3,000 rpm is covered under warranty for a period of two (2) years or 1,500 hours, whichever occurs first. If any emission related part on your engine is defective, the part will be repaired or replaced by Kohler Co.

OWNER'S WARRANTY RESPONSIBILITIES:

As the heavy-duty off-road engine owner, you are responsible for the performance of the **required maintenance listed in your Kohler Co. owner's manual**. Kohler Co. recommends that you retain all receipts covering maintenance on your heavy-duty off-road engine, but Kohler Co. cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all recommended scheduled maintenance.

As the heavy-duty off-road engine owner, you should however be aware that Kohler Co. may deny you warranty coverage if your heavy-duty off-road engine or emission control related component has failed due to abuse, neglect, improper maintenance or unapproved modifications.

Your engine is designed to operate on commercial diesel fuel (No. 1 or No. 2 low sulfur or ultra low sulfur diesel fuel) only. Use of any other fuel may result in your engine no longer operating in compliance with California's emissions requirements.

You are responsible for initiating the warranty process. The Air Resources Board suggests that you present your heavy-duty off-road engine to a Kohler Co. dealer as soon as a problem exists. The warranty repairs should be completed by the dealer as expeditiously as possible.

Please review the document titled, "Kohler Co. Federal and California Emission Control Systems Limited Warranty Off-Road Diesel Engines", for complete details of your heavy-duty off-road engine warranty. If you have any questions regarding your warranty rights and responsibilities or the location of the nearest Kohler Co. authorized service location, you should contact Kohler Co. at 1-800-544-2444 or access our website at www.kohlerengines.com.

This manual contains pertinent information regarding the repair of KOHLER air-cooled, direct injection Diesel engines type **KD 625-2 - 625-2 EPA**: updated 06/072012.

INDEX

California emission control warranty statement	4
Your warranty rights and obligations	4
1 - GENERAL REMARKS AND SAFETY INFORMATION	9
Limited 3 year kohler® diesel engine warranty	9
General service manual notes	9
Glossary and terminology	9
Safety regulations	10
General safety during operating phases	11
Safety and environmental impact	11
2 - TECHNICAL INFORMATION	12
Trouble shooting	12
Manufacturer and engine identification	14
The identification plate shown in the figure can be found directly on the engine	14
Approval data	14
Main components	15
Technical specifications	16
Fuel supply circuit	17
Lubrication circuit	17
Electrical system	17
Performance diagram	18
Overall dimension	20
3 - MAINTENANCE - RECOMMENDED OIL TYPE - REFILLING	22
Routine engine maintenance	22
Extraordinary maintenance	22
Ordinary maintenance	22
Lubricant	23
Prescribed lubricant	24
Fuel recommendations	25
4 - DISASSEMBLY / REASSEMBLY	26
Recommendations for disassembling and assembling	26
Recommendations for overhauls and tuning	26
Air cleaner	26
Oil-bath air cleaner	26
Dry air cleaner	27
Dry air cleaner, donaldson type	27
Clogging indicator	28
Oil vapour separator	28
Manifolds, intake/exhaust	28
Intake manifold	28
Exhaust manifold	28
External alternator control belt (Only for engines with external alternator)	29
External alternator blower control belt - disassembly	29
External alternator blower control belt – tension check	29
External alternator blower control belt - reassembly	29
Fuel tank	29
Pulley guard - shroud - side plates	30
Cooling fan	30
Hub	30
Internal alternator	30
Shroud support (gear cover plate)	31
Flywheel	31
Rocker arms	31
Valve / rocker arm clearance	31
Compression release (optional)	32

Rocker arm assembly	32
Injector	32
Injector for epa and 97/68 ce engines	33
Injector projection	33
Cylinder head.....	33
Valves	34
Valve stem sealing rings - reassembly	34
Valve springs.....	34
Valve material	34
Valve guides and valve guide housings.....	35
Valve guide insertion	35
Dimensions and clearance between guides and valves	35
Valve seats and housings.....	36
Valve seat grinding	36
Pushrod tube.....	36
Cylinder.....	36
Checks and cylinder roughness	36
Piston	37
Piston weight.....	38
Piston rings - end gaps (mm).....	38
Pistons rings - clearance between grooves (mm).....	38
Piston rings - fitting sequence	38
Piston - refitting	39
Piston clearance	39
Connecting rod	39
Connecting rod small end bushing	40
Connecting rod alignment.....	40
Connecting rod weight	40
Connecting rod big end bearing	40
Crankshaft timing gear.....	41
Main bearing supports.....	41
Main bearing support, gear side.....	41
Main bearing support, flywheeel side.....	41
Crankshaft.....	42
Center main bearing support, locating screw.....	42
Crankshaft removal.....	42
Crankshaft center main bearing support	42
Crankshaft lubrication ducts.....	42
Crankshaft journal radius.....	43
Checking main journals and crank pins.....	43
Main journal and crank pin diameter	43
How to measure main bearing inside diameter	43
Main bearing and connecting rod big end bearing inside diameter	44
Clearance between main journals/crank pins and connecting rod bearings	44
Main bearing supports - Dimensions.....	44
Main bearing housings.....	44
Crankshaft end play	45
Camshaft.....	45
How to measure camshaft journals and housings	45
Dimensions of camshaft journals and housings.....	45
How to measure intake/exhaust cam height.....	46
Camshaft end play	46
Camshaft timing.....	46
Valve timing without considering timing marks.....	46
Valve timing check	47
Valve timing - angles.....	47
Hydraulic pump	47
Hydraulic pump p.T.O.....	47
Hydraulic pump components (1 p).....	48
Mechanical speed governor	48
Mechanical speed governor components	48
Governor springs with rocker arm system.....	49
Governor springs with single-spring system	49
Electronic speed governor (Optional).....	49
Speed governor wiring diagram.....	50

5 - LUBRICATION SYSTEM	52
Lubrication system and breather recirculation system	52
Standard lubrication system circuit.....	52
Lubrication system with oil radiator circuit.....	53
Oil pump.....	53
Oil filter cartridge (external)	54
Oil pressure relief valve	54
Oil pressure check	55
Oil pressure curve with engine at idle speed.....	55
Oil pressure curve with engine at full speed.....	55
Oil radiator (on request).....	55
6 - FUEL SYSTEM	56
Fuel feeding / injection circuit	56
Fuel feeding / injection circuit with fuel filter inside the fuel tank.....	56
Fuel feeding / injection circuit with external fuel filter	56
Fuel feeding / injection circuit with external fuel filter and double solenoid valve	56
Fuel feeding / injection circuit with fuel filter inside the fuel tank and double solenoid valve.....	56
Fuel feeding / injection circuit with external fuel filter and qsd (quick stop system)	57
Fuel filter	57
Fuel filter (inside fuel tank).....	57
Fuel filter, external.....	57
Fuel lift pump	57
Fuel feeding pump components	58
Piston fuel lift pump (on request).....	58
Injection pump	58
Injection pump for standard and 97/68 ce engines	58
Injection pump for epa engines	59
Plunger and barrel assembly.....	59
How to check plunger and barrel for internal leakage.....	59
How to check injection pump delivery valve sealing	60
Test data for injection pump delivery	60
How to reassemble injection pump components.....	61
How to mount injection pump on the engine	61
Injection pump/mechanical speed governor timing	62
(Static) injection timing.....	62
Injection static advance adjustment.....	62
Injection advance adjustment.....	63
Injector	64
Size s injector, only for standard engines	64
Size s nozzle, only for standard engines	64
Size p injector, for 97/68 ce and epa engines.....	65
Size p nozzle, for 97/68 ce and epa engines.....	65
Injector setting	65
7 - ELECTRIC SYSTEM	66
Electric starting layout with internal alternator.....	66
Electrical starting layout with external alternator.....	66
Alternator	67
Alternator - 12 v, 18a.....	67
Alternator battery charger curve (12 v, 18 a)	67
Alternator - 24 v, 6 a	67
Alternator battery charger curve - 24 v, 6 a.....	68
Alternator - 12 v, 14 a	68
Alternator battery charger curve standard - 12 v, 14 a.....	68
Magnetization checking tool (part no. 7000-9727-001).....	68
Checking for cable continuity	69
Alternator, external - 12 v, 33 a.....	69
Alternator battery charger curve - external, 12 v, 33 a.....	69
Voltage regulator.....	70
How to check voltage regulator for proper operation	70
Voltage regulator - 12v, 26a, with "w" terminal	71
Voltage regulator - 12 v, 30 a	71
Voltage regulator - 12v, 30a, with "w" terminal	71
Characteristic curves for starting motor type bosch - 12 v, 1.7 Kw	72

Starting motor	72
Characteristic curves of the 24 v 1.6 Kw starting motor	73
Starting motor type bosch dw (r) 12 v, 1.7 Kw	73
Pre-heating glow plug	74
Direct stop electromagnets	74
Reverse electromagnet – fire version	74
Direct stop electromagnet	75
8 - SETTINGS	76
Speed adjustments	76
Idling speed setting in no-load conditions	76
Full speed setting in no-load conditions (standard)	76
Injection pump delivery setting	76
Injection pump delivery limiting and extra fuel device	76
Injection pump delivery setting with dynamometric brake	77
Injection pump delivery setting without dynamometric brake	77
Setting the stop limit stop	78
9 - STORAGE	80
Engine storage	80
Protective treatment	80
Preparing the engine for operation after protective treatment	81
10 - TORQUE SPECIFICATIONS AND USE OF SEALANT	82
Table of tightening torques for the main components	82
Table of tightening torques for standard screws (coarse thread)	84
Table of tightening torques for standard screws (fine thread)	84
11 - SPECIAL TOOLS	85
Special tools and equipment for maintenance	85

LIMITED 3 YEAR KOHLER® DIESEL ENGINE WARRANTY

Kohler Co. warrants to the original retail consumer that each new KOHLER Diesel engine sold by Kohler Co. will be free from manufacturing defects in materials or workmanship in normal service for a period of three (3) years or 2000 hours whichever occurs first from the date of purchase, provided it is operated and maintained in accordance with Kohler Co.'s instructions and manuals. If no hour meter is installed as original equipment then 8 hours of use per day and 5 days per week will be used to calculate hours used.

Our obligation under this warranty is expressly limited, at our option, to the replacement or repair at Kohler Co., Kohler, Wisconsin 53044, or at a service facility designated by us of such parts as inspection shall disclose to have been defective.

This warranty does not apply to defects caused by unreasonable use, including faulty repairs by others and failure to provide reasonable and necessary maintenance.

The following items are not covered by this warranty:

Engine accessories such as fuel tanks, clutches, transmissions, power-drive assemblies and batteries, unless supplied or installed by Kohler Co. These are subject to the warranties, if any, of their manufacturers.

KOHLER CO. AND/OR THE SELLER SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, including but not limited to labor costs or transportation charges in connection with the repair or replacement of defective parts.

IMPLIED OR STATUTORY WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. We make no other express warranty, nor is any one authorized to make any on our behalf.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

To obtain warranty service

Purchaser must bring the engine to an authorized Kohler service facility. To locate the nearest facility, visit our website, www.kohlerengines.com, and use the locator function, consult your Yellow Pages or telephone 1-800-544-2444.

ENGINE DIVISION, KOHLER CO., KOHLER, WISCONSIN 53044

GENERAL SERVICE MANUAL NOTES

- | | |
|---|--|
| <p>1 - Use only genuine Kohler repair parts.
Failure to use genuine Kohler parts could result in sub-standard performance and low longevity.</p> | <p>2 - All data presented are in metric format. That is, dimensions are presented in millimeters (mm), torque is presented in Newton-meters (Nm), weight is presented in kilograms (Kg), volume is presented in liters or cubic centimeters (cc) and pressure is presented in barometric units (bar).</p> |
|---|--|

GLOSSARY AND TERMINOLOGY

For clarity, here are the definitions of a number of terms used recurrently in the manual.

- **Cylinder number one:** is the piston timing belt side «viewed from the flywheel side of the engine».
- **Rotation direction:** anticlockwise «viewed from the flywheel side of the engine».

SAFETY REGULATIONS

GENERAL NOTES

- . Kohler engines are built to provide safe and longlasting performances, but in order to obtain these results it is essential that the maintenance requirements described in the manual are observed along with the following safety recommendations.
- . The engine has been built to the specifications of a machine manufacturer, and it is his responsibility to ensure that all necessary action is taken to meet the essential and legally prescribed health and safety requirements. Any use of the machine other than that described cannot be considered as complying with its intended purpose as specified by Kohler, which therefore declines all responsibility for accidents caused by such operations.
- . The following instructions are intended for the user of the machine in order to reduce or eliminate risks, especially those concerning the operation and standard maintenance of the engine.
- . The user should read these instructions carefully and get to know the operations described. By not doing so he may place at risk his own health and safety and that of anyone else in the vicinity of the machine.
- . The engine may be used or mounted on a machine only by personnel suitably trained in its operation and aware of the dangers involved. This is particularly true for standard and, above all, special maintenance work. For special maintenance contact personnel trained specifically by Kohler. This work should be carried out in accordance with existing literature.
- . Kohler declines all responsibility for accidents or for failure to comply with the requirements of law if changes are made to the engine's functional parameters or to the fuel flow rate adjustments and speed of rotation, if seals are removed, or if parts not described in the operating and maintenance manual are removed and reassembled by unauthorized personnel.
- . Children and animals must be kept at a sufficient distance from the machine to prevent any danger resulting from its operation.
- . Fuel is flammable, so the tank must be filled only when the engine is turned off. Dry carefully any fuel that may have spilled, remove the fuel container and any cloths soaked in fuel or oil, check that any sound-absorbing panels made of porous material are not soaked with fuel or oil, and make sure that the ground on which the machine is located has not absorbed fuel or oil.
- . Before starting, remove any tools that have been used for carrying out maintenance work to the engine and/or the machine and check that any guards removed have been replaced. In cold climates it is possible to mix kerosene with the diesel fuel to make the engine easier to start. The liquids must be mixed in the tank by pouring in first the kerosene and then the diesel fuel. Consult Kohler technical office for mixture proportions. Petrol may not be used because of the risk of it forming flammable vapours.
- . During operation the surface of the engine reaches temperatures that may be dangerous. Avoid in particular all contact with the exhaust system.
- . The liquid cooling circuit is under pressure. Do not carry out any checks before the engine has cooled down, and even then open the radiator cap or the expansion tank cautiously. Wear protective clothing and glasses. If there is an electric fan, do not approach the engine while it is still hot as the fan may come on even when the engine is not running. Clean the cooling system with the engine turned off.
- . While cleaning the oil bath air filter, check that the oil is disposed of in such a way as not to harm the environment. Any filtering sponges in the oil bath air filter should not be soaked with oil. The cyclone pre-filter cup must not be filled with oil.
- . Since the oil must be emptied out while the engine is still hot (approx. 80°C), particular care should be taken in order to avoid burns. In any case make sure that oil does not come into contact with your skin because of the health hazards involved.
- . Fuel vapours are highly toxic, so fill up only in the open air or in well ventilated environments.
- . During operations which involve access to moving parts of the engine and/or removal of the rotary guards, disconnect and insulate the positive cable of the battery so as to prevent accidental short circuits and activation of the starter motor.
- . Check the belt tension only when the engine is turned off.



WARNING

- . In addition to all other machine specifications, ensure that the engine is in a near horizontal position when starting. If starting manually, ensure that the necessary operations can be performed without any risk of striking against walls or dangerous objects. Rope starting (except for recoil rope starting) is not permitted even in emergencies.
- . Check that the machine is stable so that there is no risk of it overturning.
- . Get to know the engine speed adjustment and machine stop operations.
- . Do not start the machine in closed or poorly ventilated environments. The internal combustion process generates carbon monoxide, an odourless and highly toxic gas, so spending too long a time in an environment where the engine discharges its exhaust products freely can lead to loss of consciousness and even death.
- . The engine may not be used in environments containing flammable materials, explosive atmospheres or easily combustible powders, unless adequate and specific precautions have been taken and are clearly stated and certified for the machine.
- . To prevent the risk of fire, keep the machine at a distance of at least one metre from buildings or other machines.



IMPORTANT

- . To start the engine follow the specific instructions provided in the engine and/or machine operating manual. Do not use auxiliary starting devices not originally installed on the machine (e.g. Startpilot systems which utilise ether etc.)
- . Before carrying out any work on the engine, turn it off and allow it to cool down. Do not perform any operation while the engine is running.
- . Check that the discharged oil, the oil filter and the oil contained in the oil filter are disposed of in such a way as not to harm the environment.
- . Close the fuel tank filler cap carefully after each filling operation. Do not fill the tank right up to the top, but leave sufficient space to allow for any expansion of the fuel.
- . Do not smoke or use naked flames while filling.

- . Take care when removing the oil filter as it may be hot.
- . The operations of checking, filling up and replacing the cooling liquid must be carried out with the engine turned off and cold. Take particular care if liquids containing nitrites are mixed with others not containing these compounds as this may give rise to the formation of nitrosamines which are a health hazard. The cooling liquid is polluting, so dispose of in a manner that does not damage the environment.
- . In order to move the engine simultaneously use the eyebolts fitted for this purpose by **Kohler**. These lifting points are however not suitable for the entire machine, so in this case use the eyebolts fitted by the manufacturer.

GENERAL SAFETY DURING OPERATING PHASES

- The procedures contained in this manual have been tested and selected by the manufacturer's technical experts, and hence are to be recognised as authorised operating methods.
- Some tools are normal workshop ones, while others are special tools designed by the Manufacturer of the engine.
- All tools must be in good working condition so that engine components are not damaged and that operations are carried out properly and safely.
- It is important to wear the personal safety devices prescribed by work safety laws and also by the standards of this manual.
- Holes must be lined up methodically and with the aid of suitable equipment. Do not use your fingers to carry out this operation to avoid the risk of amputation.
- Some phases may require the assistance of more than one operator. If so, it is important to inform and train them regarding the type of activity they will be performing in order to prevent risks to the health and safety of all persons involved.
- Do not use flammable liquids (petrol, diesel, etc.) to degrease or wash components. Use special products.
- Use the oils and greases recommended by the manufacturer. Do not mix different brands or combine oils with different characteristics.
- Discontinue use of the engine if any irregularities arise, particularly in the case of unusual vibrations.
- Do not tamper with any devices to alter the level of performance guaranteed by the manufacturer.

SAFETY AND ENVIRONMENTAL IMPACT

Every organisation has a duty to implement procedures to identify, assess and monitor the influence of its own activities (products, services, etc.) on the environment.

Procedures for identifying the extent of the impact on the environment must consider the following factors:

- Liquid waste;
- Waste management;
- Soil contamination;
- Atmospheric emissions;
- Use of raw materials and natural resources;
- Regulations and directives regarding environmental impact.

In order to minimise the impact on the environment, the manufacturer now provides a number of indications to be followed by all persons handling the engine, for any reason, during its expected lifetime.

- All packaging components must be disposed of in accordance with the laws of the country in which disposal is taking place.
- Keep the fuel and engine control systems and the exhaust pipes in efficient working order to limit environmental and noise pollution.
- When discontinuing use of the engine, select all components according to their chemical characteristics and dispose of them separately.

California Proposition 65 WARNING

Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

TROUBLE SHOOTING

THE ENGINE MUST BE STOPPED IMMEDIATELY WHEN:

- 1) - The engine rpms suddenly increase and decrease;
- 2) - A sudden and unusual noise is heard;
- 3) - The colour of the exhaust fumes suddenly darkens;
- 4) - The oil pressure indicator light turns on while running.

TABLE OF LIKELY ANOMALIES AND THEIR SYMPTOMS

The following table contains the possible causes of some failures which may occur during operation. Always perform these simple checks before removing or replacing any part.

POSSIBLE CAUSE		PROBLEM										
		Engine does not start	Engine starts but stops	No acceleration	Non-uniform speed	Black smoke	White smoke	Oil pressure too low	Overheats	Inadequate performance	Excessive oil consumption	High noise level
FUEL CIRCUIT	Obstructed fuel line											
	Fuel filter clogged											
	Air or water leaks in fuel system											
	The tank cap vent hole is clogged											
	No fuel											
	Faulty fuel feeding pump											
	Extra fuel control level sticking											
COOLING CIRCUIT	Clogged air filter											
	Cooling circuit clogged											
SETTINGS REPAIRS	Incorrect governor linkage adjustment											
	Governor spring broken or unhooked											
	Low idle speed											
	Rings worn or sticking											
	Worn cylinder											
	Worn main con rod-rocker arm bearings											
	Badly sealed intake valve											
	Head tightening nuts loose											
	Damaged cylinder head gasket											
	Excessive valve-rocker arm clearance											
	No clearance between valves and rocker arms											
	Valves sticking or damaged											
	Defective timing system											
	Bent rods											
Crankshaft not turning freely												

POSSIBLE CAUSE		PROBLEM										
		Engine does not start	Engine starts but stops	No acceleration	Non-uniform speed	Black smoke	White smoke	Too low oil pressure	Overheats	Inadequate performance	Excessive oil consumption	High noise level
INJECTION	Damaged, blocked or dirty injector											
	Injection pump valve damaged											
	Injector not adjusted											
	Hardened pump control rod											
	Broken or loose supplementary start-up spring											
	Worn or damaged pumping element											
	Incorrect tuning of injection components (delivery balancing advance)											
	Extra fuel control level sticking											
LUBRICATION CIRCUIT	Oil level too high											
	Oil level low											
	Oil pressure valve blocked or dirty											
	Oil pressure regulator not adjusted											
	Worm oil pump											
	Oil sump suction line clogged											
	Faulty pressure gauge or pressure switch											
	Blocked draining pipe											
ELECTRIC SYSTEM	Discharged battery											
	Cable connection uncertain or incorrect											
	Faulty starting switch											
	Faulty starting motor											
MAINTENANCE	Excessive idle operation											
	Incomplete run-in											
	Overloaded engine											
	Non-conforming engine oil											

MANUFACTURER AND ENGINE IDENTIFICATION


The identification plate shown in the figure can be found directly on the engine.

It contains the following information:



- A) Manufacturer's identity
- B) Engine type
- C) Engine serial number
- D) Maximum operating speed
- E) Number of the customer version (form K)
- F) Approval data

Approval data

The approval reference directives EC are on the engine plate (F).



MAIN COMPONENTS



Components:

- 1) Fuel tank
- 2) Injectors
- 3) Air cleaner
- 4) Starting motor
- 5) Oil filter
- 6) Rocker arm cover

- 7) Oil dipstick
- 8) Throttle and stop controls
- 9) Oil drain plug
- 10) Fuel feeding pump
- 11) Flywheel
- 12) Injection pump

TECHNICAL SPECIFICATIONS

		KD 625 engine type		
		KD 625-2	KD 625-2 NR CE	KD 625-2 EPA
GENERAL DETAILS				
Operating cycle	Four-stroke diesel			
Cylinders	n°	2 in line		
Bore x stroke	mm	95x88	95x88	95x88
Displacements	cm ³	1248	1248	1248
Compression rate		17.5:1	20.0:1	21.0:1
Intake	Oil bath air cleaner with cyclonic prefilter or dry air cleaner			
Cooling	Air (fan integral to the flywheel)			
Crankshaft rotation	Counter-clockwise (from flywheel side)			
Combustion sequence	Driving shaft degrees	180°		
Timing system	Rods and rocker arms			
Valves	n°	2 per cylinder		
Shaft	Side camshaft in the crankcase			
Tappets	Mechanic			
Fuel injection	Direct			
Dry weight of engine	Kg	110	110	110
Maximum tilt while operating	Momentary	35°	35°	35°
Maximum tilt while operating	Up to 1 hour	25°	25°	25°
Combustion air volume at 3000 r.p.m.	l/min	1600	1600	1600
Cooling air volume at 3000 r.p.m.	l/min	26300	26300	26300
POWER AND TORQUE				
Maximum operating speed	r.p.m.	3000	3000	3000
Maximum power	N (80/1269/CEE) ISO 1585	20.7/28	-	-
	NB ISO 3046 IFN	18.8/25.5	18.8/25.5	18.8/25.5
	NA ISO 3046 ICXN	16.9/23	16.9/23	16.9/23
Maximum torque*	Nm/Kgm	73./7.4	67/6.8	68/6.9
Axial load allowed on crankshaft	Kg	300	300	300
CONSUMPTION AT MAXIMUM POWER				
Specific fuel onsumption	g/kWh - g/CV1h	253-186	258-190	258-190
Oil consumption	Kg/h	0.013	0.013	0.013


* 2200 rpm x KD 625-2; 2000rpm x KD625-2 NR/CE and 1700rpm x KD 625-2 EPA

		KD 625 engine type		
		625-2	KD 625-2 NR CE	KD 625-2 EPA
FUEL SUPPLY CIRCUIT				
Fuel type	Automotive diesel fuel (minimum cetane: 51)			
Fuel supply	Mechanical fuel lift pump (diaphragm or pistons)			
Fuel filter, internal				
<i>Filtering surface</i>	cm ²	460	460	460
<i>Filter capacity</i>	µm	7	7	7
Fuel filter, external				
<i>Filtering cartridge</i>		PF 904	PF 904	PF 904
<i>Filtering surface</i>	cm ²	5000	5000	5000
<i>Filter capacity</i>	µm	2÷3	2÷3	2÷3
<i>Maximum operating pressure</i>	bar	4	4	4
LUBRICATION CIRCUIT				
Type of lubrication	Completely forced			
Circuit supply	Gear pump			
Maximum oil quantity	including filter (l)	3.1	3.1	3.1
Maximum oil quantity	excluding filter (l)	2.8	2.8	2.8
Oil pressure at min. speed (oil temperature: 120°C)	bar	0.6	0.6	0.6
Oil pressure switch				
Unipolar system				
<i>Operating pressure (min. value)</i>	bar	0.3	0.3	0.3
Oil filter cartridge, external				
<i>Maximum operating pressure</i>	bar	13	13	13
<i>Maximum combustion pressure</i>	bar	20	20	20
<i>Filter capacity</i>	µm	15	15	15
<i>By-pass valve setting</i>	bar	1.5÷1.7	1.5÷1.7	1.5÷1.7
<i>Filtering surface</i>	cm ²	745	745	745
ELECTRICAL SYSTEM				
Alternator, Internal Standard (nominal voltage)	V	12	12	12
Alternator, Internal Optional (nominal voltage)	V	24	24	24
Alternator, External Optional (nominal voltage)	V	12	12	12
Alternator, Internal Standard (nominal current) *	A	14	14	14
Alternator, Internal Optional (nominal current) *	A	6	6	6
Alternator, External Optional (nominal current) *	A	33	33	33
Starter motor power (Bosh GF)	kW	1.7	1.7	1.7
Starter motor power (Bosh DW (R))	kW	1.6	1.6	1.6


* (see "Alternator battery charger curve" page 66 ÷ 69)

PERFORMANCE DIAGRAM


KD 625-2 EPA @ 3000 r.p.m.



KD 625 NR @ 2800 r.p.m.





KD 625 @ 3000 r.p.m.



OVERALL DIMENSION

KD 625-2



DIMENSIONI mm - MESURES mm - DIMENSION mm - EINBAUMAßE mm - DIMENSIONE mm - DIMENÇÕES (mm)													
A	434	C	557	E	340	G	198	I	421	M	599	O	207
B	397	D	217	F	168	H	425	L	178	N	633	P	542

ROUTINE ENGINE MAINTENANCE

 **Important**
Failure to carry out the operations described in the table may lead to technical damage to the machine and/or system

EXTRAORDINARY MAINTENANCE
**AFTER THE FIRST
50 WORKING HOURS**
Engine oil replacement.
Oil filter replacement.
ORDINARY MAINTENANCE

OPERATION DESCRIPTION		FREQUENCY x HOURS							
			10	125	250	500	1000	2500	5000
CHECK	ENGINE OIL LEVEL								
	OIL BATH AIR CLEANER	(***)							
	DRY AIR CLEANER	(***)							
	FUEL PIPES								
	EXTERNAL ALTERNATOR BELT TENSION	(**)							
	COOLING SYSTEM CLEANING	(***)							
	VALVE-ROCKER ARMS CLEARANCE ADJUSTMENT								
	SETTING AND INJECTORS CLEANING								
	RUBBER INTAKE HOSE (DRY AIR CLEANER - INTAKE MANIFOLD)								
	FUEL TANK CLEANING								
ALTERNATOR AND STARTING MOTOR									
REPLACEMENT	ENGINE OIL	(*)							
	EXTERNAL OIL FILTER	(*)							
	FUEL FILTER	(*)							
	EXTERNAL ALTERNATOR BELT								
	RUBBER INTAKE HOSE (DRY AIR CLEANER - INTAKE MANIFOLD)	(**)							
	FUEL PIPES	(**)							
	DRY AIR CLEANER EXTERNAL CARTRIDGE	(***)	AFTER 6 CHECKS WITH CLEANING						
DRY AIR CLEANER INTERNAL CARTRIDGE	(***)	AFTER 3 CHECKS WITH CLEANING							
OVERHAUL	PARTIAL								
	TOTAL								

(*) - In case of low use: every year.

(**) - In case of low use: every 2 years.

(***) - The period of time that must elapse before cleaning or replacing the filter element depends on the environment in which the engine operates. The air filter must be cleaned and replaced more frequently in very dusty conditions.

LUBRICANT

SAE Classification


In the SAE classification, oils differ on the basis of their viscosity, and no other qualitative characteristic is taken into account.

The first number refers to the viscosity when the engine is cold (symbol W = winter), while the second considers viscosity with the engine at régime.

The criteria for choosing must consider, during winter, the lowest outside temperature to which the engine will be subject and the highest functioning temperature during summer.

Single-degree oils are normally used when the running temperature varies scarcely.

Multi-degree oil is less sensitive to temperature changes.



International specifications

They define testing performances and procedures that the lubricants need to successfully respond to in several engine testing and laboratory analysis so as to be considered qualified and in conformity to the regulations set for each lubrication kind.

A.P.I : (American Petroleum Institute)

MIL : Engine oil U.S. military specifications released for logistic reasons

ACEA : European Automobile Manufacturers Association

Tables shown on this page are of useful reference when buying a kind of oil.

Codes are usually printed-out on the oil container and the understanding of their meaning is useful for comparing different brands and choosing the kind with the right characteristics.

Usually a specification showing a following letter or number is preferable to one with a preceding letter or number.

An SF oil, for instance, is more performing than a SE oil but less performing than a SG one.

ACEA Regulations - ACEA Sequences

Petrol

A1 =Low-viscosity, for frictions reduction

A2 =Standard

A3 =High performances

Light duty diesel engines

B1 =Low-viscosity, for frictions reduction

B2 =Standard

B3 =High performances (indirect injection)

B4 =High quality (direct injection)

Heavy duty diesel engines

E1 =~~OBSOLETE~~

E2 = Standard

E3 = Heavy conditions (Euro 1 - Euro 2 engines)

E4 = Heavy conditions (Euro 1 - Euro 2 - Euro 3 engines)

E5 = High performances in heavy conditions (Euro 1 - Euro 2 - Euro 3 engines)

API / MIL Sequences

	DIESEL							PETROL								
API	CH-4	CG-4	CF-4	CF-2	CF	CE	CD	CC	SC	SD	SE	SF	SG	SH	SJ	SL
MIL			L- 46152 D / E													
	CURRENT							OBSOLETE								

PRESCRIBED LUBRICANT

AGIP SUPERDIESEL MULTIGRADE specifications 10W40	API CF4 / SG ACEA B2 - E2 MIL - L-4165 D/E
---	---

In the countries where AGIP products are not available, use oil API SJ/CF for Diesel engines or oil corresponding to the military specification MIL-L-4165 D/E.

For a temperature of -10°C an oil with a **5W40** viscosity is recommended.

For a temperature of -15°C an oil with a **0W30** viscosity is recommended.

KD 625/2 ENGINES OIL CAPACITY		
OIL VOLUME AT MAX LEVEL (OIL FILTER INCLUDED)	Litres	3.1
OIL VOLUME AT MAX LEVEL (WITHOUT OIL FILTER)	Litres	2.8


Danger - Attention

- The engine may be damaged if operated with insufficient lube oil.
- It is also dangerous to supply too much lube oil to the engine because a sudden increase in engine rpm could be caused by its combustion.
- Use proper lube oil preserve your engine.
Good quality or poor quality of the lubricating oil has an affect on engine performance and life.
- If inferior oil is used, or if your engine oil is not changed regularly, the risk of piston seizure, piston ring sticking, and accelerated wear of the cylinder liner, bearing and other moving components increases significantly.
- Always use oil with the right viscosity for the ambient temperature in which your engine is being operated.


Danger - Attention

- The used engine oil can cause skin-cancer if kept frequently in contact for prolonged periods.
- If contact with oil cannot be avoided, wash carefully your hands with water and soap as soon as possible.
- Do not disperse the oil in the ambient, as it has a high pollution power.

FUEL RECOMMENDATIONS

Purchase diesel fuel in small quantities and store in clean, approved containers. Clean fuel prevents the diesel fuel injectors and pumps from clogging. Do not overfill the fuel tank.

Leave room for the fuel to expand. Immediately clean up any spillage during refueling.

Never store diesel fuel in galvanized containers; diesel fuel and the galvanized coating react chemically to each other, producing flaking that quickly clogs filters or causes fuel pump or injector failure.

High sulfur content in fuel may cause engine wear. In those countries where diesel has a high sulfur content, it is advisable to lubricate the engine with a high alkaline oil or alternatively to replace the lubricating oil recommended by the manufacturer more frequently. The regions in which diesel normally has a low sulfur content are Europe, North America, and Australia.

PRESCRIBED LUBRICANT	
Fuel with low sulphur content	API CF4 - CG4
Fuel with high sulphur content	API CF

FUEL TYPE

For best results, use only clean, fresh, commercial-grade diesel fuel. Diesel fuels that satisfy the following specifications are suitable for use in this engine: ASTM D-975 - 1D or 2D, EN590, or equivalent.

FUELS FOR LOW TEMPERATURES

It is possible to run the engine at temperatures below 0°C using special winter fuels. These fuels reduce the formation of paraffin in diesel at low temperatures. If paraffin forms in the diesel, the fuel filter becomes blocked interrupting the flow of fuel.

- Fuel can be: - Summer up to 0°C
- Winter up to -10°C
- Alpine up to -20°C
- Arctic up to -30°C

BIODIESEL FUEL

Fuels containing less than 20% methyl ester or B20, are suitable for use in this engine. Biodiesel fuels meeting the specification of BQ-9000, EN 14214 or equivalent are recommended. DO NOT use vegetable oil as a biofuel for this engine. Any failures resulting from the use of fuels other than recommended will not be warranted.

AVIATION FUEL

Aviation fuels suitable for use in this engine include JP5, JP4, JP8 and, JET-A (if 5 percent oil is added).

EMISSION CONTROL INFORMATION

**LOW SULFUR FUEL OR
ULTRA LOW SULFUR FUEL ONLY**

EPA /CARB emission label must be attached near the fuel inlet.

Capacities standard fuel tank	Litres	10
As for filters, tanks and special crankcases please refer to Kohler instructions.		

RECOMMENDATIONS FOR DISASSEMBLING AND ASSEMBLING



Important

To locate specific topics, the reader should refer to the index.

- Besides disassembly and reassembly operations this chapter also includes checking and setting specifications, dimensions, repair and operating instructions.
- Always use original Kohler spare parts for proper repair operations.
- The operator must wash, clean and dry components and assemblies before installing them.
- The operator must make sure that the contact surfaces are intact, lubricate the coupling parts and protect those that are prone to oxidation.
- Before any intervention, the operator should lay out all equipment and tools in such a way as to enable him to carry out operations correctly and safely.
- For safety and convenience, you are advised to place the engine on a special rotating stand for engine overhauls.
- Before proceeding with operations, make sure that appropriate safety conditions are in place, in order to safeguard the operator and any persons involved.
- In order to fix assemblies and/or components securely, the operator must tighten the fastening parts in a criss-cross or alternating pattern.
- Assemblies and/or components with a specific tightening torque must initially be fastened at a level lower than the assigned value, and then subsequently tightened to the final torque.


RECOMMENDATIONS FOR OVERHAULS AND TUNING



Important

To locate specific topics, the reader should refer to the index.

- Before any intervention, the operator should lay out all equipment and tools in such a way as to enable him to carry out operations correctly and safely.
- The operator must comply with the specific measures described in order to avoid errors that might cause damage to the engine.
- Before carrying out any operation, clean the assemblies and/or components thoroughly and eliminate any deposits or residual material.
- Wash the components with special detergent and do not use steam or hot water.
- Do not use flammable products (petrol, diesel, etc.) to degrease or wash components. Use special products.
- Dry all washed surfaces and components thoroughly with a jet of air or special cloths before reassembling them.
- Apply a layer of lubricant over all surfaces to protect them against oxidation.
- Check all components for intactness, wear and tear, seizure, cracks and/or faults to be sure that the engine is in good working condition.
- Some mechanical parts must be replaced *en bloc*, together with their coupled parts (e.g. valve guide/valve etc.) as specified in the spare parts catalogue.




AIR CLEANER

Oil-bath air cleaner

Check gaskets and replace if necessary.
Check that flange weld is free of porosity or defective spots.
Carefully clean bowl and filtering element with Diesel oil and blow through with compressed air.
Top up with engine oil to the mark.


- When refitting tighten nuts at 25 Nm.
- ➡ See page 22 for periodic maintenance details.



Components:

- 1 Bowl
- 2 Oil level mark
- 3 Filtering element
- 4 Seal ring
- 5 Internal seal ring
- 6 Cover
- 7 Clamp
- 8 Prefilter

2



Dry air cleaner


Components:

- 1 Hand wheel
- 2 Cover
- 3 Cartridge
- 4 Seal ring
- 5 Bracket
- 6 Clogging indicator

3

! Important

Replace cartridge immediately when indicator shows that is clogged.



Dry air cleaner, Donaldson type

! Danger - Attention

Never clean the filter element using highly flammable solvents. It could cause an explosion!

➔ In order to know how often you should check and replace the air filter cartridge and the rubber hose (air filter – intake manifold) see page 22.

- 1 Main cartridge
- 2 Safety cartridge
- 3 Axial cover
- 4 Scavenging valve
- 5 Cap complete with clamp

4

Scavenging valve 4 must be positioned as in figure 4.

! Danger - Attention

During repair operations, when using compressed air, wear eye protection.

The cartridge can be cleaned by blowing compressed air breadthways outside and inside the cartridge, at a pressure not greater than 5 atmospheres, or in necessity case by knocking the front of the cartridge several times against a flat surface.


Use a lamp to check that the filter element is not damaged or inspect it against the light while slanted.

In case of doubt, install a new cartridge.

Clogging indicator

Components:
 1 Reset button
 2 Transparent indicator


Note: Indicator is calibrated at 600÷650 mm column of water.



5

Oil vapour separator

Fitted on engines with dry air cleaner.
 Screw it out of the air conveyor support, carefully wash with gasoline inside and blow out with compressed air.
 When refitting replace the copper gasket and connect the oil vapour separator with intake manifold by means of the special rubber hose.



6

7


MANIFOLDS, INTAKE/EXHAUST

Intake manifold

To avoid flange breakage check that heads are in line before tightening nuts.
 Check flange surface for warpage and correct if necessary.
 Replace gaskets.

○ Tighten nuts at 25 Nm.

Note: In case of low temperature starting we can supply a manifold with possibility of fitting a glow plug with air preheating.




8


Exhaust manifold

Check that the inside is clean.
 To avoid flange breakage check that heads are in line before tightening nuts.
 Replace gaskets.

○ Tighten nuts at 20 Nm.



9



10

EXTERNAL ALTERNATOR CONTROL BELT (only for engines with external alternator)

External alternator blower control belt - Disassembly

Release the two alternator fastening bolts.
Unscrew the fastening nuts of the belt guard and remove it.
Remove the V belt.

➔ See page 22 for periodic maintenance details.



11

External alternator blower control belt – Tension check



Important

Carry out checks only after isolating the positive battery cable to prevent accidental short-circuiting and, consequently, the activation of the starter motor.

Tension the belt if it flexes more than 1 cm exerting a pressure of 10 kg.



12


External alternator blower control belt - Reassembly

Install the belt and the belt guard.

Force the alternator outwards and temporarily tighten the fastening bolts.

Make sure that the belt tension is within the required parameters (see “External alternator blower control belt – Tension check”, Fig. 11).

○ Tighten the fastening bolts to a final torque of 30 Nm (8x1.25) and 50 Nm (10x1.50).



13

FUEL TANK

After disconnecting the fuel pipes unscrew the anchoring brackets' screws and remove the fuel tank.


Completely empty the tank and check that no impurities are found inside. If the fuel tank is fitted with an internal fuel filter remove and replace the cartridge.

Check that cap breather hole is not clogged.

Remove the tank support.

○ When refitting tighten the support screws at 40 Nm and the bracket screws at 8 Nm.


➔ See page 57 for refitting internal fuel filter.



Pulley guard - Shroud - Side plates

- Components:*
 1 Pulley guard
 2 Shroud
 3 Side plates


The pulley guard is made of sound deadening material: it reduces the noise that both the pulley and the fan tend to amplify. Shroud and side plates are made of ANTIFON, an elastic layer which absorbs the noise caused by the plate vibrations.



Cooling fan

Carefully clean and check all blades and inserts. Replace the fan even if there is only a single damaged blade or only a single released insert.

- ➡ See page 16 for cooling air flow.
- Tighten the fan's fixing screws at a torque of 10 Nm.




Hub

- Components:*
 1 Hub
 2 Alternator rotor
 3 Fan
 4 Bolt

The hub holds the alternator rotor and the cooling fan.


- Unscrew the bolt clockwise and tighten at 160 Nm when refitting.



Internal alternator

Remove stator and place it inside the rotor to prevent metal particles from being attracted by the magnets.

- When refitting tighten rotor screws and stator bolts at 10 Nm.
- ➡ See page 67 ÷ 69 for alternator characteristics.




18

Shroud support (Gear cover plate)

Loosen screws and remove shroud support very carefully to avoid damage to the oil seal ring.
When refitting check that gaskets **A** and oil seal ring **B** are well inside their housings.

- Tighten screws at 25 Nm.



19

FLYWHEEL

Remove flywheel with puller **1** (part N°. 7271-1460-119).
Check starter ring gear and tapered crankshaft mating surfaces.

- When refitting tighten bolt at 300 Nm.


In order to replace the ring gear, it is necessary to disassemble the flywheel.

Cut the ring gear in several places using a chisel and remove it.



Important

Remove any debris and carefully clean the ring gear.



20

Heat the new ring gear uniformly and keep it at a temperature of 300°C for 15÷20 minuti.




Danger – Attention

Risk of burning: be careful of hot surfaces.

Insert the ring gear into its seat and place it carefully on the rim of the flywheel.

Leave to the ring gear to cool gently before reassembling the flywheel.



21

22

ROCKER ARMS

Valve / Rocker arm clearance




Important

Setting should be performed when the engine is cold.

Remove rocker arm cover and check gaskets for breakage.



Bring each cylinder piston to top dead center on the compression stroke and set clearance **A** at 0.15÷0.20 mm for intake and 0.30÷0.35 mm for exhaust.

- When refitting tighten cover screws by 20 Nm.



Compression release (optional)

Bring piston to top dead center on the compression stroke.
 Unscrew rocker arm cover side plug and measure clearance **A** between lever and rocker arm, which must be 0.30÷0.40 mm.
 For setting purposes remove the rocker arm cover, unscrew the lock nut **C** and set clearance **A** by changing the height of the shims under the plate **B**.
 Set the valve/rocker arm clearance, see "Valve / Rocker arm clearance" on page 31.
 Reassemble the rocker arm cover and check the decompression lever clearance again.



Rocker arm assembly

Components:

- 1 Bore
- 2 Lubrication tube

Dimensions (mm):

- A** = 18.032÷18.050
- B** = 17.989÷18.000

If clearance (**A - B**) exceeds 0.135 mm replace shaft and rocker arms.




Caution – Warning

When retitting check that lubrication tube perfectly matches with the journal bore.

On slow engines, which are set to 1,500 – 1,800 rpm, the rocker arms differ from the standard version in the upper part of the lubrication channel.


- Tighten the rocker arm shaft fastening screws to the head at a torque of 25 Nm.



INJECTOR

Clean injector and check calibrated pressure as indicated on page 65.
 When refitting check that it correctly protrudes from the cylinder head plane.

- Tighten the fixing nuts at 10 Nm.
- Tighten the high-pressure pipe union at 25 Nm.




27

Injector for EPA and 97/68 CE engines

The injector is attached to the cylinder head via a forked bracket.

- Tighten the fixing bracket screw at 10 Nm.
- Fix the high-pressure hose union to the injector union at 25 Nm.




28

Injector projection

The end of nozzle **A** should project 3.0±3.5 mm. from the cylinder head plane.

Adjust injector projection by means of copper shims **B** measuring 0.5, 1.00 and 1.50 mm in thickness.



29

CYLINDER HEAD



Important

Do not remove it when hot to avoid deformation.


The cylinder heads must be tightened with the exhaust or intake manifold mounted to keep them lined up.

If cylinder head is deformed level it off by removing a maximum of 0.3 mm.

When refitting tighten only if sure that rocker arm lubrication tube is well inside its holes, and that the rubber seals of the tappet hose are assembled and inserted correctly into their seats.

Always replace copper head gasket: see page 39 for choosing the right thickness.

- Progressively tighten nuts in the **1, 2, 3, 4** sequence at 55 Nm.




Valves

Components:

- 1 Intake valve
- 2 Spring seat
- 3 Valve stem seal ring
- 4 Spring
- 5 Retainer
- 6 Half collets

To remove half collets firmly press down as shown in the figure.




Valve stem sealing rings - Reassembly

Lubricate the inside of the sealing ring with Molikote BR2 Plus and insert them all the way onto the guides using tool 1460-108.

To prevent deformation of the sealing ring 1 as it is inserted onto the valve guide 2 insert it onto tool 3.

Lubricate valve stem with the same type of grease; insert the valves into the guides rotating them particularly as they enter the sealing ring.




Valve springs

Measure free length with a gauge.

Using a dynamometer check that the spring length under two different loads corresponds to the values below:

- Free length **A** = 52 mm
- Length **B** compressed by a 210.6 N = 35.8 mm
- Length **C** compressed by a 340.6 N = 25.8 mm

Replace spring if length is 1 mm or more below the stated values.



Valve material

Intake valves A


Material: X 45 Cr Si 9-3 UNI En 10090

- 1 Chromium-plated portion
- α 45.5° ÷ 45.75°

Exhaust valve B

Shaft and head are made of 2 different materials.

- 2 Welded portion
- 3 Chromium-plated portion
- 4 Portion made of X 45 Cr Si 9 - 3 UNI EN 10090
- 5 Portion made of X 55 Cr Mn Ni N 20 - 8 UNI EN 10090
- α 45.5° ÷ 45.75°



37

Valve guides and valve guide housings


Starting from engine No. 2883619 intake and exhaust valve guides are both made of phosphoric cast iron.

Components:

- 1 = Exhaust valve guide
- 2 = Intake valve guide

Ref.	Dimensions (mm)
A	42.0
B	48
C	14.000 ÷ 14.018
D	14.045 ÷ 14.056

Valve guides with outside diameter increased by 0.5 mm. are also available; in such cases valve guide bore **C** should also be increased by 0.5 mm.




38

Valve guide insertion

Heat cylinder head up to 160÷180°C

Press guides considering the **A** and **B** distances from the head plane.

Ref.	Dimensions (mm)
A	30,80÷31,20
B	24,80÷25,20




39

Dimensions and clearance between guides and valves

Ref.	Dimensions (mm)	Clearance (mm)	Limit value (mm)
A	8,025÷8,040*	0,025÷0,055	0,15
B	7,985÷8,000		


* with driven guide.



Valve seats and housings


Ref.	Dimensions (mm)
A	40.000 ÷ 40.016
B	40.081 ÷ 40.095
C	34.000 ÷ 34.016
D	34.081 ÷ 34.095

Press valve seats into the housings and cut at 45°.




Valve seat grinding

After cutting grind valve seats with fine emery paste in oil suspension. The sealing surface **S** should not exceed 2 mm. Valve recess after grinding **D** = 0.75÷1.25 mm; maximum worn limit 1.65 mm.



Pushrod tube


When refitting check that gaskets **A** and rocker arm lubrication tube **C** are well inside their seats.




CYLINDER

Checks and cylinder roughness

Fins must be intact. Cross hatch pattern must range between 125°÷135°: they must be uniform and clear in both directions. Average roughness should range between 0.35 and 0.60 µm.




45




46

Measure diameter size between two diametrically opposed points at three different heights.

➔ As per the cylinder sizes, see Table "Piston and cylinder types and sizes".



47



48

PISTON

Remove circlips and remove piston pin.
Remove piston rings and clean grooves.
Measure diameter at 17 mm from the bottom of skirt.

Table "Piston and cylinder types and sizes"

Class	Ø Piston (mm)	Ø Cylinder (mm)	Clearance (mm)
A	94.92 ÷ 94.93 *	95.00 ÷ 95.01 *	0.07 ÷ 0.09
B	94.93 ÷ 94.94 *	95.01 ÷ 95.02 *	
C	94.94 ÷ 94.95 *	95.02 ÷ 95.03 **	

* In case of diameter wear above 0.05 mm replace piston and piston rings.


** In case wear exceeds 0.10 mm, bore the cylinder and fit oversize piston and rings.
In case of less wear replace piston rings only.

Note: Oversize pistons of 0.5 and 1.0 mm are available (only for standard and 97/68 CE engines).



Important

The cylinder heads must be tightened with the exhaust or intake manifold mounted to keep them lined up.
The cylinder and piston must be replaced with a new cylinder and piston of the same class.



Piston weight

Weigh pistons when replacing them in order to avoid unbalance.

Important


The difference in weight should not exceed 6 g.



Piston rings - End gaps (mm)


Place piston rings squarely into the unworn part of the lower cylinder and measure the end gap.

		A
1°	Chromium-plated ring	0.40mm÷0.65mm
2°	Torsional internal tapered ring	0.40mm÷0.65mm
3°	Oil control ring	0.30mm÷0.60mm



Pistons rings - Clearance between grooves (mm)

Ref.	Dimensions (mm)	Limit value (mm)
A	0,07÷0,11	0,20
B	0,05÷0,09	0,16
C	0,04÷0,08	0,15




Piston rings - Fitting sequence

- A = 1° Chromium-plated ring
- B = 2° Torsional (internal tapered) ring
- C = 3° Oil control ring


Important

Before fitting the piston into the cylinder stagger the ring gaps at 120°.



Piston - Refitting

Connect piston to connecting rod in a way that the combustion chamber centre **b** is at right angle under nozzle tip **a**.
Lubricate piston pin and introduce it into the piston by exerting pressure with your thumb.
Check that both circlips are well inside their seats.





Piston clearance

Piston clearance = 0.65 ÷ 0.70 mm, for standard engines
= 0.55 ÷ 0.60 mm, for 97/68 CE and EPA engines

The piston in the **TDC** (top dead centre) position may extend or be short of the upper surface of the cylinder.
Use a dial indicator to measure the difference between the two surfaces (piston crown and upper cylinder surface) and use a suitable thickness copper gasket **B** for the cylinder head to adjust the clearance volume **A**.

(See image below)



CONNECTING ROD

Remove the oil sump.
Remove the connecting rod cap.



Important

Both connecting rod/piston units should be fitted back into the corresponding cylinders; mark them so as to identify the correct combination during reassembly.

➔ See page 40 for specifications as to the tightening of the connecting rod big end bearing.

Connecting rod small end bushing


Dimensions and clearance (mm):

C = 25.020÷25.030 (with machined bushing in place)

D = 24.995÷25.000

(C-D) = 0.020÷0.035


(C-D) maximum worn limit = 0.070



60

Connecting rod alignment

Check alignment of small end and big end bearing bores using fitted mandrels; axial mis-alignment **A** = 0.02 mm; maximum limit = 0.05 mm.



61


Connecting rod weight

Weigh connecting rods when replacing them in order to avoid unbalance.



Important

The difference in weight should not exceed 10 g.




62

Connecting rod big end bearing


Both centering notches of the bearings **A** and **B** must be on the same side when refitting.

○ Tighten bolts at 40 Nm.


➡ See page 44 for dimensions.



63



64



65

Crankshaft timing gear

Disassembly:

Use tool 1 (Part N°. 7560-4000-052) and puller 2 (Part N°. 7271-1460-119) to remove the gear.

Reassembly:

Heat the gear uniformly and keep it at a temperature of 300 °C for 15 – 20 minutes.




Caution – Warning

Danger of burning: pay attention to the hot surfaces.

Insert the gear into its seat by inserting the activation key into the gear opening and push until it comes into contact with the driving shaft.

Let it slowly cool down.



66

MAIN BEARING SUPPORTS


Main bearing support, gear side

Remove main bearing by means of two M8x1.25 screws with fully threaded length of 40 mm or a puller (Part N°. 7271-1460-119).

Note: To avoid deformation it is not recommended to replace the bearing bushing, complete assembly's of bushing and support are available in standard, 0.25 mm and 0.50 mm undersize configurations as spare parts.

○ When refitting tighten the screws at 30 Nm.

➔ See page 44 ÷ 45 for dimensions.



67

Main bearing support, flywheel side

Remove it by means of two M8x1.25 screws with fully threaded length of 40 mm.

Check oil seal ring and replace if warped, hardened or worn-out.

○ When refitting, tighten nuts at 30 Nm.

➔ See end float on page 45 for gasket replacement details.


➔ See page 44 ÷ 45 for dimensions.

CRANKSHAFT

Center main bearing support, locating screw.

Straighten plate 1 and unscrew screw 2 before removing crankshaft.

- When assembling tighten the screw at a torque of 30 Nm.




68

Crankshaft removal

To pull out the crankshaft tap lightly on the timing side end using a copper-headed hammer.

When refitting align center main bearing support so that the locating screw hole coincides with the crankcase hole.




69

Crankshaft center main bearing support

When refitting, both centering notches **A** and **B** must be located on the same side.

- Tighten screws at 25 Nm.

- ➡ See page 44 ÷ 45 for dimensions.



70


Crankshaft lubrication ducts




Danger - Attention

During repair operations, when using compressed air, wear eye protection.


Remove plugs, clean duct **A** with a pointed tool and blow in compressed air. Screw plugs again and check for sealing.



71



72



73


Crankshaft journal radius

The radius **R** connecting journals to shoulders is 2.8÷3.2 mm.



Important


When grinding external main journals restore the **R** value to original specification.



74

Checking main journals and crank pins


Use an outside micrometer gauge.



75

Main journal and crank pin diameter


Ref.	Dimensions (mm)
A	54.931÷54.950
B	45.500÷45.516
C	55.331÷55.350
D	54.931÷54.950



76

How to measure main bearing inside diameter

Use an inside micrometer gauge.




77

Main bearing and connecting rod big end bearing inside diameter

Ref.	Dimensions (mm)
E	55.000÷55.020
F	45.548÷45.578
G	55.404÷55.435
H	55.000÷55.020

The above dimensions refer to driven in or tightened bearings.


Note: Both main bearings and connecting rod big end bearings are available with inside diameter size measuring 0.25 and 0.50 mm less than the standard version.



78

Clearance between main journals/crank pins and connecting rod bearings

Ref.	Clearance (mm)	Limit value (mm)
E-A	0.050÷0.089	0.180
F-B	0.032÷0.078	0.150
G-C	0.054÷0.104	0.190
H-D	0.050÷0.089	0.180




79

Main bearing supports - Dimensions

- 1 Flywheel side
- 2 Central
- 3 Gear side

Ref.	Dimensions (mm)
I	149.000 ÷ 149.020
L	60.000 ÷ 60.020
M	147.000 ÷ 147.018
N	59.074 ÷ 59.093
O	75.990 ÷ 76.010
P	60.000 ÷ 60.020
Q	23.95 ÷ 24.05
R	31.10 ÷ 31.20




80

Main bearing housings

Ref.	Dimensions (mm)
A	149,000÷149,020
B	147,000÷147,020
C	76,000÷76,020

Table "Clearance between main bearings and main bearing housings"

Ref.	Clearance (mm)	Limit value (mm)
A-I	-0.020 ÷ 0.020	0.03
B-M	-0.018 ÷ 0.020	0.03
C-O	-0.010 ÷ 0.030	0.04



Crankshaft end play


When refitting crankshaft check end play by means of a thickness gauge; this value should be $0.08 \div 0.38$ mm and can be set by changing the thickness of gasket **A** which is located on the flywheel-side main bearings.

Gaskets with thickness of 0.30 and 0.50 mm can be supplied.



Important


Replace the main bearings **1** and **3** (Fig. 79) if the axial clearance value still turns out to be too high even with a seal having a smaller thickness (fig. 79).



CAMSHAFT


How to measure camshaft journals and housings

Use an inside micrometer gauge for housings and an outside micrometer gauge for journals.



Dimensions of camshaft journals and housings

Ref.	Dimensions (mm)	Clearance (mm)	Limit value (mm)
A	41.940÷41.960	0.040÷0.085	0.160
C	42.000÷42.025		
B	27.940÷27.960	0.040÷0.085	0.150
D	28.000÷28.025		




How to measure intake/exhaust cam height

A1 = 1 st cylinder intake cam
S1 = 1 st cylinder exhaust cam
A2 = 2nd cylinder intake cam
S2 = 2nd cylinder exhaust cam

Exhaust and intake cams feature the same height **H**.


H = 33.625 ÷ 33.650 mm

Replace camshaft if **H** is 0.1 mm below the given value.



Camshaft end play


End play should be 0.10÷0.25 mm; check by means of a dial gauge pushing or pulling camshaft as required.



CAMSHAFT TIMING


Fit camshaft gear by making timing mark **1** coincide with timing -mark **2** on the crankshaft timing gear.

- Tighten camshaft bolt at 60 Nm.



Valve timing without considering timing marks

Locate piston **1** (on flywheel side) at the top dead centre.
 Position two small cylinders **A** of the same height onto the tappets.
 Rotate camshaft stopping when cylinder **1** tappets are in overlap position (intake open, exhaust closed).
 By means of ruler **B** check that tappets are at the same height.
 Engage camshaft gear with crankshaft gear.



90

Valve timing check


Check valve timing at the crankshaft.

The values shown are checked at the flywheel circumference (with flywheel of 291 mm. diameter each degree corresponds to 2.5 mm).

Set valve clearance at 0.65 ± 0.70 mm (after checking restore the value at 0.15 ± 0.20 mm).

Set dial gauge on intake valve to a zero value; by rotating the driving shaft according to its direction of rotation you can measure α (intake valve opening advance referred to top dead centre **S**) and β (intake valve closing delay referred to bottom (I) dead centre).

Follow the same procedure for exhaust valves checking γ (exhaust valve opening advance) and δ (exhaust valve closing delay).



91

Valve timing - Angles

The angle values are determined by turning the driving shaft clockwise

S = Piston at top dead centre

I = Piston at bottom dead centre

α = Intake valve open

β = Intake valve closed

γ = Exhaust valve open

δ = Exhaust valve closed


Timing angles for checking puposes
(valve clearance = $0,65 \pm 0,70$ mm)

α = 1° before **S**

β = 21° after **I**

γ = 23° before **I**

δ = 1° after **S**




92

HYDRAULIC PUMP

Hydraulic pump p.t.o

A hydraulic pump of group 1 (**1P**) or 2 (**2P**) can be installed on the gear side, 3rd p.t.o.

Hydraulic pump components (1 P)




- 1 Seal ring
- 2 Centering ring
- 3 Coupling
- 4 Half coupling
- 5 Flange
- 6 Gear
- 7 Bracket
- 8 Thrust washer
- 9 Stop ring
- 10 Cover


The maximum total torque is thus 30 Nm corresponding to 12.5 HP at 3000 r.p.m. Reduction ratio 1:1.

MECHANICAL SPEED GOVERNOR

Weight-type governor housed inside the camshaft drive gear.



Mechanical speed governor components




- 1 Gear
- 2 Weight
- 3 Mobile bell
- 4 Stop ring
- 5 Thrust washer
- 6 Yoke
- 7 Lever
- 8 Drive rod
- 9 Governor spring
- 10 Rack control lever

Weights are moved to the periphery by the centrifugal force and thus axially shift a mobile bell connected to the injection pump rack control lever by a linkage.

A spring placed under tension by the accelerator control offset the weight centrifugal force.

Balance between the two forces keeps speed at an almost constant level in spite of load variations.


➡ See page 62 for timing.



Governor springs with rocker arm system


The system features two springs anchored to a rocker arm and allows for minimal r.p.m. changes at low speed levels.

The device is operated automatically: when the engine is stopped spring 6 acts on injection pump control yoke 7 providing maximum fuel delivery, until the engine starts and the governor controls the injection pump rack.




Components:

- 1 Rocker arm for spring anchoring
- 2 Governor springs
- 3 Plate
- 4 Link
- 5 Throttle lever
- 6 Supplementary start-up fuel spring



Governor springs with single-spring system

- 1 Extra fuel spring
- 2 Injection pump control lever
- 3 Governor spring
- 4 Throttle lever



ELECTRONIC SPEED GOVERNOR (optional)

- 1 Injection pump control lever
- 2 Electromagnet
- 3 Eccentric screw
- 4 Conical plug
- 5 Conical plug
- 6 Actuator
- 7 Eccentric screw


Assemble the entire plate by centring it on the reference pins and make sure that the injection pump rack rod pin is inside lever "1". Fix the plate by using the specific screws for its model.

Adjustment of the stroke end (STOP):

- 1 - Remove the conical plug "5".
- 2 - Through the eccentric "7" position and check by sight that the lever in stop position is at the extreme left.
- 3 - From this position, always acting on the eccentric screw "7", move the control lever 1,0 ÷ 1,5 mm to right.
- 4 - Lock the lock nut of the screw "7".
- 5 - Reassemble the conical plug "5".


Adjustment of extra fuel delivery:

- 1 - Remove the conical plug "4".
- 2 - Power the electromagnet "2" with a 12V voltage and make sure that the plunger has moved. In this case you will hear the typical activated magnet sound.
- 3 - Feed actuator "6" with a tension of 12V (put between the actuator and the 12V a 10 Amp. fuse): the actuator tension will cause the pump delivery control lever to move to the right.
- 4 - By the eccentric screw "3" place and check by sight that the lever in Max position is at the extreme right; from this position, always acting on the screw "3", move the delivery control lever by 1,0 ÷ 1,5 mm to the left .
- 5 - Lock the lock nut of screw "3".
- 6 - Remove feeding from actuator "6" e electromagnet "2".
- 7 - Reassemble the conical plug "4".



100

Speed governor wiring diagram



101


LUBRICATION SYSTEM AND BREATHER RECIRCULATION SYSTEM

Danger – Attention

- The engine can be damaged if allowed to operate with insufficient oil. It is also dangerous to add too much oil because its combustion may lead to a sharp increase in the rotation speed.
- Use suitable oil in order to protect the engine. Nothing more than lubrication oil can influence the performances and life of an engine.
- Use of an inferior quality oil or failure to regularly change the oil will increase the risk of piston seizure, will cause the piston rings to jam and will lead to rapid wear on the cylinder liner, the bearings and all other moving parts. Engine life will also be notably reduced.



Danger – Attention

- The oil viscosity must suit the ambient temperature in which the engine operates.
- Old engine oil can cause skin cancer if repeatedly left in contact with the skin and for long periods of time. Wear protective gloves to avoid touching used oil.
- If contact with the oil is unavoidable, you are advised to wash your hands with soap and water as soon as possible. Dispose of old oil in the correct way as it is highly polluting.

Standard lubrication system circuit

102
Components:

- | | |
|---|---------------------------------------|
| 1) Oil pressure gauge | 9) Oil fill plug |
| 2) Breather | 10) Rocker arm shafts |
| 3) Connecting rod big end bearing | 11) Pushrod protection tube |
| 4) Crankshaft main bearing on gear side | 12) Hydraulic pump gear |
| 5) Cartridge filter | 13) Camshaft journal on flywheel side |
| 6) Oil pressure relief valve | 14) Oil dipstick |
| 7) Oil pump | 15) Oil drain plug |
| 8) Internal filter | |


Lubrication system with oil radiator circuit




103

Components:

- | | |
|---|---------------------------------------|
| 1) Oil pressure gauge | 9) Oil fill plug |
| 2) Breather | 10) Rocker arm shafts |
| 3) Connecting rod big end bearing | 11) Pushrod protection tube |
| 4) Crankshaft main bearing on gear side | 12) Hydraulic pump gear |
| 5) Cartridge filter | 13) Camshaft journal on flywheel side |
| 6) Oil pressure relief valve | 14) Oil dipstick |
| 7) Oil pump | 15) Oil drain plug |
| 8) Internal filter | 16) Oil radiator |



104




105

OIL PUMP

Check that the gear teeth are intact and that clearance between gear edge and pump body does not exceed 0.15 mm. Furthermore check that the control shaft is free to rotate with end float not exceeding 0.15 mm. Oil pump delivery at 3000 r.p.m. is 9 liters/min.

OIL FILTER CARTRIDGE (EXTERNAL)




- Components:*
- 1 Gasket
 - 2 Plate
 - 3 Gommino
 - 4 Spring
 - 5 Filter element
 - 6 Bypass valve
 - 7 Spring

➡ For characteristics see page 17.

106

OIL PRESSURE RELIEF VALVE



- Details:*
- 1 Plunger
 - 2 Washer
 - 3 Valve body
 - 4 Spring
 - 5 Ring snap
 - 6 M9x1 threading for puller

Operation start pressure.....5 bar.

107

Disassembly:

Before removing the oil pressure regulating valve, remove the oil filter by using an appropriate wrench.

Remove the regulating valve using a hammer puller equipped with a M9x1 threaded terminal.



108


Reassembly:

Make sure that the valve seat is free of scratches and scores which could reduce the pressure seal.

Insert the entire oil pressure valve into its housing by keeping it in line.
Make sure that the valve is completely assembled to the engine guard by means of a pad.




109



110

Oil pressure check

Once the engine is fitted fill with oil and fuel; connect a 10 bar pressure gauge to the fitting. Start the engine and check pressure as a function of the oil temperature .




111

Oil pressure curve with engine at idle speed

The curve is obtained at the oil filter lever with constant engine speed of 1200 r.p.m. in no-load conditions and at a room temperature of + 25°C. Pressure is given in bar and temperature in centigrades.

If the oil pressure value is below the indicated one, please check all components indicated on page 52 ÷ 53.




112

Oil pressure curve with engine at full speed

The curve is obtained at the oil filter level with engine working at 3000 r.p.m. and max. power at + 25°C room temperature. Pressure is given in bar and temperature in centigrades.

If the oil pressure value is below the indicated one, please check all components indicated on page 52 ÷ 53.



113

OIL RADIATOR (on request)

Components:


- 1 Radiator
- 2 Return pipe
- 3 Oil filter
- 4 Copper gasket
- 5 Delivery hose
- 6 Union
- 7 Oil detection flange
- 8 O-ring

FUEL FEEDING / INJECTION CIRCUIT

Fuel feeding / injection circuit with fuel filter inside the fuel tank

Components:

- 1 Fuel tank
- 2 Fuel filter
- 3 Fuel feeding tube
- 4 Fuel lift pump
- 5 Injection pump
- 6 High-pressure pipe
- 7 Injector
- 8 Injector exhaust pipe




114

Fuel feeding / injection circuit with external fuel filter

Components:

- 1 Fuel tank
- 2 Fuel feeding tube
- 3 Fuel filter
- 4 Fuel lift pump
- 5 Injection pump
- 6 High-pressure pipe
- 7 Injector
- 8 Injector exhaust pipe




115

Fuel feeding / injection circuit with external fuel filter and double solenoid valve

Components:

- 1 Fuel tank
- 2 Solenoid valve
- 3 Fuel filter
- 4 Fuel lift pump
- 5 Solenoid valve
- 6 Injection pump
- 7 High-pressure pipe
- 8 Injector
- 9 Injector exhaust pipe
- 10 Non-return valve




116


Fuel feeding / injection circuit with fuel filter inside the fuel tank and double solenoid valve

Components:

- 1 Fuel tank
- 2 Fuel filter
- 3 Solenoid valve
- 4 Fuel lift pump
- 5 Solenoid valve
- 6 Injection pump
- 7 High-pressure pipe
- 8 Injector
- 9 Injector exhaust pipe
- 10 Non-return valve



117




118

Fuel feeding / injection circuit with external fuel filter and QSD (Quick Stop System)

Components:

- 1 Fuel tank
- 2 Fuel feeding tube
- 3 Fuel filter
- 4 Fuel lift pump intake tube
- 5 Fuel lift pump delivery tube
- 6 Fuel lift pump
- 7 Injection pump
- 8 High-pressure pipe
- 9 Injector
- 10 Injector exhaust pipe



119


FUEL FILTER

Fuel filter (inside fuel tank)

Components:

- 1 Spring
- 2 Disc
- 3 Ring
- 4 Cartridge
- 5 Gasket
- 6 Gasket
- 7 Cap
- 8 Ring
- 9 Screw

➔ For characteristics see page 17.




120

Fuel filter, external

- 1 Air relief valve
- 2 Support
- 3 Cartridge
- 4 Gasket
- 5 Filtering element

➔ For characteristics see page 17.

➔ For maintenance see page 22.



121

FUEL LIFT PUMP

The fuel lift pump is of the diaphragm type operated by a camshaft eccentric through a drive rod. It features an external lever for manual operation.


Fuel feeding pump components

Components:

- 1 Drive rod: - length: 32,55 ÷ 32,65 mm
- measured protrusion **A**: 1,47 ÷ 2,07 mm
- 2 Gasket
- 3 Camshaft eccentric
- 4 Manual priming lever

Characteristics:

when the control eccentric rotates at 1000 r.p.m. minimum delivery is 73 l/h while self-regulation pressure is 0.5 ÷ 0.7 bar.



122

Piston fuel lift pump (on request)


Characteristics:

when the control eccentric rotates at 1000 r.p.m. minimum delivery is 65 l/h while self-regulation pressure is 1.5 ÷ 2.5 bar.



Important

The drive rod and its protrusion do not change in relation to the diaphragm pump.




123

INJECTION PUMP

The injection system consists of a single-body pump with plungers featuring constant stroke and feeding one cylinder each. The pump, mounted on the crankcase is directly operated by the camshaft.

Speed governor, extra fuel and stop device are separate from the pump (see pages 48, 49, 50 and 78).




124


Injection pump for Standard and 97/68 CE engines

Components:

- | | |
|-------------------------------|--------------------|
| 1 Pump body | 9 Gasket |
| 2 Holder-delivery valve | 10 Rack |
| 3 O-ring | 11 Metering sleeve |
| 4 Filter | 12 Tappet spring |
| 5 Shim | 13 Upper retainer |
| 6 Valve spring | 14 Lower retainer |
| 7 Delivery valve | 15 Tappet |
| 8 Plunger and barrel assembly | 16 Tappet roller |



125




Injection pump for EPA engines

Components:

- 1 Holder-delivery valve
- 2 Locking nut clamp
- 3 Screw
- 4 Valve-Spring
- 5 O Ring
- 6 Copper gasket
- 7 Plunger and barrel assembly
- 8 Pin spring
- 9 Rack
- 10 Seat spring
- 11 Spring tappet
- 12 Seat phasing
- 13 Ring snap
- 14 Tappet assembly roller
- 15 Pin tappet driver
- 16 Pump housing
- 17 Metering sleeve
- 18 Pin barrel locating
- 19 Copper gasket
- 20 Gasket fibre seal
- 21 Threaded cap
- 22 Delivery valve assembly

126



Plunger and Barrel Assembly

- 1 Barrel
- 2 Fuel feeding port
- 3 Control helix
- 4 Plunger
- 5 Retardation notch


Plunger diameter is 7.5 mm.



Important

Every plunger matches with its own barrel. For this reason they are not interchangeable.

127



How to check plunger and barrel for internal leakage

This operation is only indicative since pressure changes depending on the pumping speed.

Connect the delivery union with a 600 bar pressure gauge with safety valve.

Adjust rack rod at half-stroke.

Turn flywheel according to its direction of rotation so that the plunger puts the circuit under pressure.

Replace plunger if the displayed pressure is below 300 bar.


Repeat the same operation for the other plunger.

128

How to check injection pump delivery valve sealing


Components:
1 Valves
2 Seat

Adjust pump rack at half-stroke.
 Turn flywheel according to its direction of rotation so that the plunger puts the circuit under pressure.
 During this operation the displayed pressure will gradually reach a peak followed by a sudden drop which corresponds to valve closing.
 Pressure drop should be 30÷50 bar.
 Replace the valve if pressure drop is below this value.
 Repeat the same operation for the other plunger.




Test data for injection pump delivery

Check only maximum plunger difference by positioning rack rod according to the indicated delivery value.



Control rod max. force	Rod stroke from max deliv. point	R.P.M.	Delivery	Max. plunger difference
Newton	mm		mm ³ /stroke	mm ³ /stroke
0,50	10	1500	34÷37	3
	13	500	7÷11	3
	0	150	70÷78	-----
	10	500	22÷26	3

Control rod max. force	Rod stroke from max deliv. point	R.P.M.	Delivery	Max. plunger difference
Newton	mm		mm ³ /stroke	mm ³ /stroke
0,50	9.5	1500	34÷37	3
	11.5	500	3÷7	3
	0	150	60÷68	-----
	9.5	500	13÷18	3




132

How to reassemble injection pump components

After replacing the worn-out components, reassemble the pump as follows:

- Introduce sector gears into the pump body by making reference points **C** match with the **B** points on the rack.
- Fix barrels with the eccentric screws **F** on the pump body.
- Fit valves with seats, springs, fillers and delivery unions tightening them at 35 ÷ 40 Nm.
- Fit plungers by making reference points **E** match with the sector gear **D** points.
- Fix retainers and springs; lock tappet with special stop.
- Check that both plungers have the same delivery by performing the necessary measurements at the test bed; if delivery is not the same set screw **F**.




133

134

How to mount injection pump on the engine

During reassembly, make sure the adjustment rod pin **1** is correctly inserted into the opposite seat in the adjustment lever.


- ➔ See "Injection advance adjustment" on page 63 for the choice of the seals **2**.



135


- Tighten screws at 25 Nm.

Check that rack rod slides smoothly: if not, the engine may fail to start or hunt.



Injection pump/mechanical speed governor timing


Loosen screw 1
 Move injection pump lever 2 to maximum delivery (to the right).
 Check that drive rod 3 closes the speed governor; keeping lever 2 pressed to the right the drive rod should have no clearance.
 Tighten screw 1.



(STATIC) INJECTION TIMING

Injection static advance adjustment

- 1 Remove rocker arm covers and high-pressure pipes.
- 2 Select the cylinder on which the injection static advance check will be carried out.
- 3 Assemble the valve lowering tool (1460.285) by fastening it to the fixing holes of the rocker arm cover screws.
- 4 Before tightening the tool fixing screws, make sure that the dial indicator tracer is correctly placed on the intake valve collar.
- 5 Place the auxiliary tank at a higher height than the one of the injection pump (~30-40 cm).
- 6 Connect the tank to the injection pump fuel supply hole.
- 7 Slowly rotate the crankshaft clockwise keeping lever 1 lowered and the valve positioned on the piston crown, until the dial indicator 2 shows the maximum measurement.
- 8 Set the maximum measurement dial indicator to zero which is equivalent to the compression top dead centre.
- 9 Assemble the advance tester 4 (serial number 1460.024) on the injection pump delivery union of the cylinder corresponding to the one on which the valve lowering tool has been previously installed.



- 10 Rotate the crankshaft clockwise by approximately 45°.

- 11 Rotate the crankshaft alternately until the fuel leaks out from tester 4 with a certain pressure.

- 12 Position the stop lever 3 half a stroke so that the plunger delay mark is excluded and keep the lever in this position.




136

137

138

139




140

- 13 Turn the flywheel slowly and clockwise. Stop turning as soon as you notice that the fuel is moving inside tester 4.
- 14 Move lever 1 again so as to lower the valve and bring it again in contact with the piston.
- 15 Measure the piston lowering value and bring it again in contact with the piston.
- 16 Convert the registered value from millimetres to degrees (see Table "Conversion for establishing advance").

Table "Conversion for establishing advance"

Engine type	R.p.m.	Advance degrees	Piston lowering value (mm)
KD625/2	3000	26° ± 1° *	24° 4.94
			25° 5.34
			26° 5.76
			27° 6.21
KD625/2 EPA	3000	17° ± 1° *	15° 1.96
			16° 2.22
			17° 2.51
			18° 2.81
KD625/2 CE NR	3000	18° ± 1° *	17° 2.51
			18° 2.81
			19° 3.12

* Check values.



141

Injection advance adjustment

If the values indicated in the table do not correspond to the detected ones, follow the operations as written below:

- 1) Delayed Injection Advance: remove the shims under the pump until the detected value corresponds to the one indicated in the Table "Conversion for establishing advance"
- 2) Advanced Injection Advance: add shims under the pump until the detected value corresponds to the one indicated in the Table "Conversion for establishing advance".


Note: By removing or adding a 0.1 mm shim under the pump, it is possible to advance or delay the injection by about 1°.

INJECTOR

Size S Injector, only for standard engines

Components:

- 1 Intake fitting
- 2 Nozzle holder
- 3 Shim
- 4 Spring
- 5 Pressure rod
- 6 Intermediate flange
- 7 Nozzle
- 8 Needle valve
- 9 Fixing flange
- 10 Taper pin
- 11 Gasket
- 12 System duct
- 13 Sump



142


Size S Nozzle, only for standard engines

Features:


- Hole number and diameter4x0.28 mm.
- Jet angles 160°.
- Needle valve elevation0.20 ÷ 0.22 mm

Clean nozzle tip with a brass brush.
Check that holes are not obstructed using a mandrel with steel wire with 0.28 mm diam.

- When refitting tighten ring nut at 60 Nm.



143




144

Size P injector, for 97/68 CE and EPA engines

Components:

- 1 Injector housing
- 2 Intake fitting
- 3 Shim
- 4 Spring
- 5 Pressure rod
- 6 Taper pin
- 7 Nozzle
- 8 Cup
- 9 Needle valve
- 10 Sump
- 11 System duct
- 12 Overflow pipe



145


Size P nozzle, for 97/68 CE and EPA engines

Features:

- Hole number and diameter 5 x 0.23 mm.
- Jet angles 150°.
- Needle valve elevation 0.200 ÷ 0.205 mm

Clean nozzle tip with a brass brush.
Check that holes are not obstructed using a mandrel with steel wire with 0.23 mm diam.

- When refitting tighten ring nut at 42 ÷ 48 Nm.




146

Injector setting

Connect the injector to a diesel injector calibration pump.
Check needle valve sealing by slowly moving hand pump until approximately 180 bar and maintain this pressure for 10 seconds.
Check that setting pressure is 210 ÷ 220 bar for standard engines (245 ÷ 230 bar for EPA e CE engines); make the required adjustments, if any, by modifying the adjusting shim height.


When replacing the spring, setting should be performed at a 10 bar greater pressure (255 ÷ 265 bar) to allow for bedding during operation.
Replace nozzle in case of dripping.

Electric starting layout with internal alternator




147

Electrical starting layout with external alternator



148



149

ALTERNATOR

Alternator - 12 V, 18A


Features a fixed armature winding mounted on the air shroud bracket. The rotating permanent magnet inductor is located in the fan spindle. Only the two yellow cables are at output.

Dimensions (mm):

A = 158.80÷159.20

B = 27.50÷27.90


Note: Clearance between armature winding and inductor (air gap) must be 0.48÷0.60 mm.



150

Alternator battery charger curve (12 V, 18 A)

This curve is obtained at +25°C with 12.5 V battery voltage.



151

Alternator - 24 V, 6 A


Features a fixed armature winding mounted on the air shroud bracket. The rotating permanent magnet inductor is located in the fan spindle. There are the two yellow cables and one red cable at output.

Dimensions (mm):

A = 158.80÷159.20

B = 27.50÷27.90


Note: Clearance between armature winding and inductor (air gap) should be 0.48÷0.60 mm.



152

Alternator battery charger curve - 24 V, 6 A

The curve was obtained at room temperature of +20°C with 25 V battery voltage.




153

Alternator - 12 V, 14 A

Features a fixed armature winding mounted on the air shroud bracket. The rotating permanent magnet inductor is located in the fan spindle. There are the two yellow cables and one red cable at output.

Dimensions (mm):
A = 158.80÷159.20
B = 27.50÷27.90


Note: Clearance between armature winding and inductor (air gap) should be 0.48÷0.60 mm.



154

Alternator battery charger curve standard - 12 V, 14 A

The curve was obtained at room temperature of +25°C with 12,5 V battery voltage.




155

Magnetization checking tool (Part No. 7000-9727-001)

- Components:*
- 1 Casing
 - 2 Slider
 - 3 Casing reference line
 - 4 Slider reference line


Rest the tool end horizontally onto the magnetic poles. Hold slider so that its reference line coincides with the casing reference line. Release slider: if no attraction occurs the rotor is demagnetized, in this case replace alternator.



156

Checking for cable continuity

Check that stator windings have no unsoldered connections, burnt areas or grounded wires. Using an ohmmeter check for continuity between the red cable and the two yellow ones. Furthermore, check that they are insulated from the ground.



157


Alternator, external - 12 V, 33 A

The alternator is of the claw-pole rotor type with built-in voltage regulator. The rotating motion is conveyed by the engine through a "V" belt and sheave.

Features:

Rated voltage 12V
 Max. current..... 33 A (at 7000 alternator r.p.m./min.).
 RH direction of rotation.

- Tighten the nut 1 at a torque of 70 Nm.




158

Alternator battery charger curve - external, 12 V, 33 A

The curve was obtained at room temperature of + 25°C. Battery terminal voltage is 12.5 V. The r.p.m. shown on the table refers to the engine.


VOLTAGE REGULATOR

Type Kohler, supplied by SAPRISA and DUCATI: Voltage 12 V, max. current 26A.



159

To avoid wrong connections 3 different sizes are supplied.



160

Connections	Dimensions (mm)	
	Width	Thickness
~	6.35	0.80
R	9.50	1.12
+	9.50	1.12
LE	4.75	0.50
⏏	6.35	0.80


How to check voltage regulator for proper operation

- Check that connections correspond to the layout.
- Disconnect the terminal from the battery positive pole.
- Connect a d.c. voltmeter between the two battery poles.
- Fit an ammeter between the positive pole and the B+ of the voltage regulator (corresponding to ref. 1 in the picture).
- Start a couple of times until battery voltage drops below 13 V.
- When battery voltage reaches 14.5 V the ammeter current suddenly drops down to almost zero.
- Replace regulator if recharge current is zero with voltage below 14V.




Caution - Warning

- When the engine is running do not disconnect battery cables or remove the key from the control panel.
- Keep regulator away from heat sources since temperatures above 75°C might damage it.
- No electric welding on engine or application.




161



Voltage regulator - 12V, 26A, with "W" terminal

"W" pole tab:
Width = 4,75 mm;
Thickness= 0,5 mm.


➔ See page 70 for tag dimensions.



Voltage regulator - 12 V, 30 A

The voltage regulator is of the bridge type.


➔ See page 70 for tag dimensions.



Voltage regulator - 12V, 30A, with "W" terminal

"W" pole tab:
Width = 4,75 mm;
Thickness= 0,5 mm.

➔ See page 70 for tag dimensions.



165

STARTING MOTOR



Important

- Made by MARELLI and BOSCH.
- Apply to their distributors for any type of repair.

Bosch starting motor type GIF - 12 V, 1.7 kW

RH direction of rotation.

- A = 29.5÷31.5 mm
- B = Ring gear plane
- C = Flange plane




Caution – Warning

Flywheel should not project from ring gear plane B.


Characteristic curves for starting motor type Bosch - 12 V, 1.7 kW

Curves are obtained at room temperature of + 20°C with 66 Ah battery.

- V = Motor terminal voltage in Volt
- P = Power in kW
- C = Torque in N/m
- N = Motor speed in r.p.m.
- J (A) = Absorbed current in Ampere.



166



Starting motor type Bosch DW (R) 12 V, 1.7 kW

RH direction of rotation.

A = 29.5÷31.5 mm

B = Ring gear plane

C = Flange plane



Caution – Warning

Flywheel should not project from ring gear plane B.

Characteristic curves of the 24 V 1.6 kW starting motor

The curves have been measured at a 20°C temperature with an 88 Ah battery.


V = Voltage to the motor terminals in Volt

P = Power in kW

C = Torque in N/m

N = Motor speed in rpm

J (A) = Absorbed current in Amperes.



168


Pre-heating glow plug

- Components:*
- 1 Sheath
 - 2 Regulation filament
 - 3 Heating filament

○ When remounting tighten at a torque of 20 Nm.

Glow plug Type	12 V	24 V
Nominal voltage	12 V	28 V
Current	41 A	13 A

Note: The glow plug is not damaged in any way due to the prolonged activation time.



169

DIRECT STOP ELECTROMAGNETS

Reverse electromagnet – FIRE version

Features:

Electromagnet type	12 V	24 V
Operating tension	12 V	24 V
Power coil absorption	40 A	20 A
Hold coil absorption	0.63 A	0.30 A

Components:

- 1 Nut
- 2 Stud bolt
- 3 Flat washer
- 4 Screw
- 5 Spacer
- 6 Spherical joint
- 7 Electromagnet
- 8 Stop control lever
- 9 Axial joint
- 10 Stop control electromagnet support

Adjustment:

- Carry out the adjustments by screwing and unscrewing the joints.
- Adjust the device so as to make the electromagnet get to the end of the stroke before the STOP lever reaches its limit stop after performing the operation stroke.
- When the electromagnet is excited, put the stop lever at about 1.0 – 1.5 mm from its limit stop.
- Once adjustment phase is completed, tighten nut 1.



Important

The control cover should not present the return spring of the stop lever.


Remove the stop lever return spring without replacing the control cover if the device is applied to engines that were originally not equipped with it.

Direct stop electromagnet*Features:*

Operating tension 12V.
Power coil absorption 41 A.
Hold coil absorption 0.5 A.

Setting:

- Screw drive rod 1 to the end of the thread on the electromagnet piston.
- Excite the electromagnet and leave the stop lever in normal operation position.
- Bring drive rod 1 in contact with the stop lever and tighten lock nut 2.



170

SPEED ADJUSTMENTS




WARNING

- Adjustments should be carried out by Kohler authorised personnel only.
- Any tampering with the adjustment immediately makes the warranty null and void.

Idling speed setting in no-load conditions

After filling with oil and fuel, start the engine and let it warm up for 10 minutes.

Adjust idling speed at 1000±1100 r.p.m. by turning setscrew 1; then tighten lock nut.




171

Full speed setting in no-load conditions (standard)

After setting idle speed turn screw 2 and set full speed in no-load conditions at 3200 r.p.m.; then tighten lock nut.

Note: When the engine reaches the pre-set power full speed stabilizes at 3000 r. p. m.

Not valid on EPA engines, on which it is not possible to modify the adjustment of the maximum.



172

Injection pump delivery setting



Important

This adjustment must be performed with the engine connected to the dynamometric brake. Without this the regulation is approximate.

Injection pump delivery limiting and extra fuel device

Limiting device C limits the injection pump maximum delivery.


It also acts as a torque setting device since spring N opposes the resistance of spring M inside the cylinder through lever L.

The torque setting device allows lever L to move over stroke H corresponding to 0.15±0.25 mm.


This consequently increases injection pump delivery with torque reaching its peak value.

Note: In generator sets and power welders, the torque setting device acts as a delivery limiter only.

It therefore does not feature spring M or stroke H.




173



174

Injection pump delivery setting with dynamometric brake

- 1) Run the engine and bring it to the operating temperature.
- 2) Release the flow limiter screw **C** completely (see page 175).
- 3) Bring the engine to maximum rotation speed.
- 4) Activate the dynamometric brake to bring the engine to the maximum speed.
- 5) Check that fuel consumption is in line with the values given in the table "Specific fuel consumption".
If it is not in line with the indicated values, reduce the dynamometric brake load.
- 6) After a few operation minutes and when the engine has stabilized, slowly fasten screw **C** until the rotation speed starts decreasing.
- 7) Lock screw **C** using a lock nut.
- 8) Carry out the fuel consumption check again.
- 9) Release the dynamometric brake and detect the rotation speed of the "stabilized" engine (maximum idle speed).
- 10) Bring the engine to minimum idle speed. Carry out engine setting when the engine is "stabilized".
- 11) Switch off the engine and let it cool down.
- 12) Check the valve/rocker arm clearance (see "Setting valve/rocker arm clearance").



175

Injection pump delivery setting without dynamometric brake


Loosen delivery limiting device **C** by 5 turns.
Bring engine to full speed in no-load conditions i.e. 3200 r.p.m.. Tighten limiting device until the engine shows a drop in r.p.m..
Unscrew limiting device **C** by 1 and ½ turns.
Tighten lock nut.

Note: If the engine, under full load, generates too much smoke tighten **C**; if no smoke is observed at the exhaust and the engine cannot reach its full power unscrew **C**.

Required settings (as most commonly applies)

Engine	R.p.m.	Power HP (kW)	Specific fuel consumption *	
			Time (sec) per 100 cm ³	g/HP h (g/kW h)
KD 625-2	3000	NB 25.50 (18.80)	60÷63	190÷200 (258÷272)
KD 625-2	1800	NB 18.50 (13.6)	90÷95	171÷181 (233÷246)
KD 625-2	1800	NA 16.50 (12.13)	104÷110	163÷173 (223÷235)
KD 625-2	1500	NB 14.80 (10.88)	110÷116	175÷185 (239÷252)
KD 625-2	1500	NA 13.30 (9.78)	125÷132	169÷178 (230÷243)
KD 625-2 EPA	3000	NB 25.57 (18.80)	60.5÷61.5	190÷194 259÷264
KD 625-2 CE	3000	NB 25.50 (18.80)	59÷60	190 (258)

The indicated specific fuel consumption refers to the period following approximately 30 working hours.



Setting the stop limit stop

- 1) Remove the throttle lever cover.
- 1) Completely turn lever **C** counter-clockwise and keep it in this position. Retainer **F** should not be in contact with lever **C**.
- 2) Unscrew nut **G** and bring retainer **F** in contact with lever **C**
- 3) Push retainer **F** so that lever **C** is moved backwards clockwise by 1.0 mm.
- 4) Lock retainer **F** by screwing nut **G**

Note: In this condition, the limit stops of the injection pump adjustment rod will not be damaged by the violent impacts caused by the possible assembly of electrostop.

ENGINE STORAGE

- **When the engines are not for more than 6 months, they have to be protected performing the operations described in the following pages.**
- If the engine is not to be used for extensive periods, check the storage area conditions and the type of packaging and make sure that these are suitable for correct storage.
If necessary, cover the engine with a proper protective sheet.
- Avoid storing the engine in direct contact with the ground, in environments that are humid and exposed to bad weather, near high voltage electric lines, etc.

**Important**

If, after the first 6 months, the engine is still not used, it is necessary to carry out a further measure to extend the protection period (see "Protective treatment").

PROTECTIVE TREATMENT

- 1 - Pour in the engine housing AGIP RUSTIA C protective oil up to the maximum level.
- 2 - Fill up with fuel containing 10% AGIP RUSTIA NT.
- 3 - Start the engine and keep it idle at minimum speed for some minutes.
- 4 - Bring the engine to $\frac{3}{4}$ of the maximum speed for 5÷10 minutes.
- 5 - Turn off the engine.
- 6 - Empty out completely the fuel tank.
- 7 - Spray SAE 10W on the exhaust and intake manifolds.
- 8 - Seal the exhaust and intake ducts to prevent foreign bodies from entering.
- 9 - Thoroughly clean all external parts of the engine using suitable products.
- 10 - Treat non-painted parts with protective products (AGIP RUSTIA NT).
- 11 - Loosen the alternator/fan belt (if present).
- 12 - Cover the engine with a proper protective sheet.

**Caution - Warning**

In countries in which AGIP products are not available, find an equivalent product (with specifications: MIL-L-21260C).

**Important**

Maximum every 24 months of inactivity, the engine must be started up by repeating all "Engine Storage" operations.

PREPARING THE ENGINE FOR OPERATION AFTER PROTECTIVE TREATMENT

After the storage period and before starting up the engine and preparing it for operation, you need to perform certain operations to ensure maximal efficiency conditions.

- 1 - Remove the protective sheet.
- 2 - Remove any sealing devices from the exhaust and intake ducts.
- 3 - Use a cloth soaked in degreasing product to remove the protective treatment from the external parts.
- 5 - Inject lubricating oil (no more than 2 cm³) into the intake ducts.
- 6 - Adjust the alternator/fan belt tension (if present).
- 7 - Turn the engine manually to check the correct movement and smoothness of the mechanical parts.
- 8 - Refill the tank with fresh fuel.
- 9 - Make sure that the oil is up to the maximum level.
- 10 - Start the engine and after some minutes bring it to $\frac{3}{4}$ of the maximum speed for 5-10 minutes.
- 11 - Turn off the engine.
- 12 - Remove the oil drain plug (see "Oil replacement") and discharge the AGIP RUSTIA NT protective oil while the engine is hot.
- 13 - Pour new oil (see "Table of lubricants") up to the maximum level.
- 14 - Replace the filters (air, oil, fuel) with original spare parts.

**Caution - Warning**

Over time, a number of engine components and lubricants lose their properties, so it is important considering whether they need replacing, also based on age (see Replacement table).

**Important**

Maximum every 24 months of inactivity, the engine must be started up by repeating all "Engine Storage" operations.

Table of tightening torques for the main components

POSITION	Diam. and pitch (mm)	Torque (Nm)	Sealant
Vibration-damping tank support	-	-	Loctite 270
Connecting rod	8x1.0	40	
Injection pump delivery valve union	18x1.5	40	
Rocker arm cover	8x1.25	20	
Center main bearing support	8x1.25	25	
Intake manifold	8x1.25	25	
Exhaust manifold	8x1.25	25	
Air shroud	6x1.0	6	
Accelerator cover	6x1.0	10	
Governor control cover	6x1.0	10	
Air conveyor shroud	8x1.25	20	
Alternator cable clamp	6x1.0	10	
High pressure fuel line clamp	5x0.8	5	
Air cleaner	8x1.25	25	
Hydraulic pump flange	8x1.25	25	
Air conveyor shroud gasket	-		Loctite 495
Head injector	6x1.0	10	Loctite 270
Camshaft gear	10x1.5	60	
Oil pump gear	10x1.5	35	Loctite 270
Air conveyor sheet	6x1.0	10	Loctite 242
Internal oil filter pierced plate	6x1.0	10	
Breather sheet	6x1.0	10	
Starting motor	10x1.5	45	
Blower hub	14x1.5	160	
Nippl radiator	14x1.5	40	
Rocker arm shaft	8x1.25	25	
Injection pump control lever pivot	8x1.25	15	
Speed governor external control lever pivot	8x1.25	10	
External stop control lever pivot	8x1.25	10	
Governor spring lower lever pivot	8x1.25	10	
Gear cover plate	8x1.25	25	
Engine mounting foot	10x1.5	40	
Fuel feeding pump	8x1.25	25	
Injection pump	8x1.25	25	
Oil pump	8x1.25	20	
Nozzle holder	6x1.0	10	
Oil pan	8x1.25	30	
Oil pressure switch	12x1.5	25	
Starter motor fixing stud	10x1.5	12	Loctite 270
Fuel lift pump fixing stud	8x1.25	8÷10	Loctite 270
Cylinder head fixing stud	10x1.5	15	Loctite 270
Cooling fan guard	6x1.0	10	
Starting pulley	10x1.5	45	
Fuel filter union	14x1.5	40	
Fuel lift pump union	10x1.0	12	
High pressure fuel line union	12x1.5	25	
Fuel bleeding line union	8x1.0	10	
Voltage regulator	8x1.25	20	
R.p.m. counter driving gear	5x0.8	5	
Main bearing support, gear case side	8x1.25	30	
Main bearing support, flywheel side	8x1.25	30	
Center main bearing support	10x1.5	30	
Air conveyor support	8x1.25	25	
Hydraulic pump gear support	8x1.25	20	
Injection pump control lever support	8x1.25	25	
Governor lever support (camshaft seal)	8x1.25	25	
Governor fork support	8x1.25	25	
Fuel tank bracket	8x1.25	30	
Alternator stator	5x0.8	7	Loctite 242

POSITION	Diam. and pitch (mm)	Torque (Nm)	Sealant
Crankcase lubrication plug	8x1.25	15	
Oil drain plug	14x1.5	40	
Cylinder head	10x1.5	55	
Blower	6x1.0	10	Loctite 270
Cooling fan hub fixing screw	16x1.5	160	Loctite 270
Flywheel	20x1.5	300	

Table of tightening torques for standard screws (coarse thread)

Resistance class (R)								
Quality/ Dimensions								
Diameter	R>400N/mm ²		R>500N/mm ²		R>600N/mm ²	R>800N/mm ²	R>1000N/mm ²	R>1200N/mm ²
	Nm	Nm	Nm	Nm	Nm	Nm	Nm	Nm
M3	0,5	0,7	0,6	0,9	1	1,4	1,9	2,3
M4	1,1	1,5	1,4	1,8	2,2	2,9	4,1	4,9
M5	2,3	3	2,8	3,8	4,5	6	8,5	10
M6	3,8	5	4,7	6,3	7,5	10	14	17
M8	9,4	13	12	16	19	25	35	41
M10	18	25	23	31	37	49	69	83
M12	32	43	40	54	65	86	120	145
M14	51	68	63	84	101	135	190	230
M16	79	105	98	131	158	210	295	355
M18	109	145	135	181	218	290	405	485
M20	154	205	193	256	308	410	580	690
M22	206	275	260	344	413	550	780	930
M24	266	355	333	444	533	710	1000	1200
M27	394	525	500	656	788	1050	1500	1800
M30	544	725	680	906	1088	1450	2000	2400

Table of tightening torques for standard screws (fine thread)

Resistance class (R)								
Quality/ Dimensions								
Diameter	R>400N/mm ²		R>500N/mm ²		R>600N/mm ²	R>800N/mm ²	R>1000N/mm ²	R>1200N/mm ²
	Nm	Nm	Nm	Nm	Nm	Nm	Nm	Nm
M 8x1	10	14	13	17	20	27	38	45
M 10x1	21	28	26	35	42	56	79	95
M 10x1,25	20	26	24	33	39	52	73	88
M 12x1,25	36	48	45	59	71	95	135	160
M 12x1,5	38	45	42	56	68	90	125	150
M 14x1,5	56	75	70	94	113	150	210	250
M 16x1,5	84	113	105	141	169	225	315	380
M 18x1,5	122	163	153	203	244	325	460	550
M 18x2	117	157	147	196	235	313	440	530
M 20x1,5	173	230	213	288	345	460	640	770
M 20x2	164	218	204	273	327	436	615	740
M 22x1,5	229	305	287	381	458	610	860	1050
M 24x2	293	390	367	488	585	780	1100	1300
M 27x2	431	575	533	719	863	1150	1600	1950
M 30x2	600	800	750	1000	1200	1600	2250	2700

Special tools and equipment for maintenance

SPECIAL TOOLS	DESCRIPTION	Part N°.
	<p>Valve lowering tool for static injection timing check 1 Spacers, h=40mm 2 Dial gauge indicator 3 Dial gauge extension</p>	<p>1460 - 285</p>
	<p>Static timing tool</p>	<p>1460 - 024</p>
	<p>Tool for valve stem O-ring assembly</p>	<p>1460 - 047</p>
	<p>Flywheel puller</p>	<p>1460 - 119</p>
	<p>Timing control gear extractor fork</p>	<p>7560-4000- 052</p>

Translated from the original manual in Italian language.

Data reported in this issue can be modified at any time by KOHLER.

KOHLER®

FOR SALES AND SERVICE INFORMATION
IN U.S. AND CANADA, CALL **1-800-544-2444**

KohlerEngines.com

ENGINE DIVISION, KOHLER CO., KOHLER, WISCONSIN 53044

FORM NO.	ED0053029380		
ISSUED	06/07/2012		
REVISED	00	DATE	06/07/2012