

INSTALLATION INSTRUCTIONS

75423T Hidden Floor Drain

BEFORE YOU BEGIN


All information is based on the latest product information available at the time of publication. Kohler Co. reserves the right to make changes in product characteristics, packaging, or availability at any time without notice.

Please leave these instructions for the consumer. They contain important information.

NOTES:


1. Observe all local plumbing codes.
2. According to rough-in dimensions, drain stub-out should be prearranged in the floor.

ROUGH-IN DIMENSIONS




75423T

INSTALLATION




To drain easily, the mounting position of hidden floor drain must be at the lowest area of the whole finished floor.

Determine the height of prearranged stub-out according to the diameter of drain pipe and the height of intended finished floor.



Mount the hidden floor drain(1) according to the determined height. Position it. Adjust the nuts(2) to ensure the drain align with the floor. Fill up the interspace around it with cement.



The size of opening on the tile is as the figure shown. Lay the tile.


Fill up the gap between the floor drain and tile with cement. Remove any excess cement.

CLEANING INSTRUCTIONS

All Finishes: Clean the finish with mild soap and warm water. Wipe entire surface completely dry with clean soft cloth. Many cleaners may contain chemicals, such as ammonia, chlorine, toilet cleaner etc. which could adversely affect the finish and are not recommended for cleaning.

Do not use abrasive cleaners or solvents on Kohler faucets and fittings.

SERVICE PARTS



**Color code must be specified when ordering