
KOHLER SERVICE PARTS

COMPONENTS



Color code must be specified when ordering. NOTE: For all Asia pacific regions (excluding China) add SP (SPxxxxxx) in front of the part number when ordering.

KOHLER INSTALLATION INSTRUCTIONS

77965T		Widespread
77966T		Widespread
23887T		Widespread
77967T	77967T-MU	Widespread
77968T	77968T-MU	Widespread
77969T	77969T-MU	Widespread
77985T		Deck-mount
77986T		Deck-mount
77987T		Deck-mount
77990T-4		Lever Handle
77990T-8	77990T-8MU	Oyl Handles
77990T-9		Industrial Ha
77963T-8A		Rocker Hand

BEFORE YOU BEGIN

All information is based on the latest product information available at the time of publication. Kohler Co. reserves the right to make changes in product characteristics, packaging, or availability at any time without notice.

Please leave these instructions for the consumer. They contain important information.

NOTES:

- 1. Flush the water supply pipes thoroughly to remove debris.
- 2. If possible, install this faucet before installing the lavatory or bath tub.
- 3. Inspect the supply tubing for damage and leakage. Replace and maintain as necessary.
- 4. Observe local plumbing codes.

5. Shut off the water supplies to the fitting

STANDARD APPLICABLE

Special model meets or exceeds the following at date of manufacture: TIS

HANDLE OPERATION

For 77990T-4, right handle open with turning clockwise, left handle open with turning counter-clockwise.


For 77990T-8/8MU/9, left handle open with turning clockwise, right handle open with turning counter-clockwise.

For 77963T-8A, When facing front of the faucet, gently push the handle forward to open the faucet, the direction of the red dot is for hot water and the blue dot is for cold water.


COMPONENTS

- d Lavatory Faucet Tube High Spout
- d Lavatory Faucet Ribbon High Spout
- d Lavatory Faucet Row High Spout
- Lavatory Faucet Tube Spout
- d Lavatory Faucet Ribbon Spout
- Lavatory Faucet Row Spout
- t Bath Faucet Tube Spout
- t Bath Faucet Ribbon Spout
- t Bath Faucet Row Spout
- les

andles dle












COMPONENTS



















Color code must be specified when ordering. NOTE: For all Asia pacific regions (excluding China) add SP (SPxxxxxx) in front of the part number when ordering.


COMPONENTS

KOHLER® **SERVICE PARTS**

COMPONENTS








**Color code must be specified when ordering.

NOTE: For all Asia pacific regions (excluding China) add SP (SPxxxxxx**) in front of the part number when ordering.





SERVICE PARTS 77965T 77967T 77967T-MU 23887T 77969T 77969T-MU 1102292-1102292-870992 đ ė ~870858 Ò 77965T/77967T/77967T-MU:3027000** 23887T/77969T/77969T-MU:1318807* -3016159 -22352 3028156 3027230 831587 3026813 1112775


Color code must be specified when ordering. NOTE: For all Asia pacific regions (excluding China) add SP (SPxxxxxx) in front of the part number when ordering.


COMPONENTS

- Widespread Lavatory Faucet Tube High Spout
- Widespread Lavatory Faucet Tube Spout
- Widespread Lavatory Faucet Row High Spout
- Widespread Lavatory Faucet Row Spout









For 77966T, 77968T, 77968T-MU

Put the washer(12) into the groove of the escutcheon(13). Insert the spout kit(14) into the mounting hole of the lavatory with washer.

From underside of the lavatory, place the washer(15), steel washer(16) and fixing ring(17) onto the shank(18). Position the faucet. Screw the fixing ring. Tighten the screws(19) to secure the spout.

Put the plastic washer(20), rubber gasket (21) into the supply tee(22). Thread supply tee to the shank.

Connect the hoses(23) and supply tee. The other end of the hoses should be connected to the side bodies.

When used with 77963T-8A, the hoses (23) needn't to be installed.

For 77986T

Put the washer(24) into the groove of the escutcheon(25). Insert the spout kit(26) into the mounting hole of the bathtub with washer .


From underside of the bathtub, place the washer(27), steel washer(28) and fixing ring(29) onto the shank(30). Position the faucet. Screw the fixing ring. Tighten the screws(31) to secure the spout.


Install the supply tee(32) to the shank and tighten by the hook(33).


Put the washers(34) into each end of the hoses(35). Connect the hoses and tee supply. The other end of the hoses should be connected to the side bodies.

3

(2)







53

(7)

Ensure the valves and handle kits are in the off position.

For 77990T-4/9

Screw the handle kits(52, 53) onto the nuts(50). **NOTE:** The handle kit with "H" should be installed on the left.

For 77990T-8/8MU

Screw the handle kit(55) onto the nut(50) with handle wrench(56).

Uninstall the handle wrench. Remove the O-ring(54), separate it into two parts as shown. **NOTE:** The handle kit with "H" should be installed on the left.

The figure shown is the correct position of the handles in the closed position.

8

How to Install the Handle Kit (77963T-8A)

Install the washer(58) into the groove of the handle kit(57). Insert the handle kit with washer to the mounting hole. Adjust the handle. Make sure the handle with red dot is on the left side and blue dot on the right side.

From underside, slide the washer(60), washer(61) and threaded ring(62) to the body(59). Screw the threaded ring. Tighten the screws(63) to secure the handle kit.

Attach the two hoses(64) to water supplies. Make sure the hose with red label should be connected to hot water, the hose with blue label should be connected to cold water. Connect another hose(65) and tee supply. Install the plug(67) with washer(66) to other end of tee supply.

9