



<p>Record your model number.</p>	<p>⚠ CAUTION: Risk of personal injury. Do not use this product as a grab or support bar when entering or exiting the bath. The product is not designed to support weight.</p>	<p>NOTICE: Adequate floor support is required. Standard 2x6 lumber is NOT sufficient for this application. NOTE: Concrete can be used as the floor support. Observe all local plumbing and building codes.</p>	<p>1 Roughing-In</p>	<p>2 Roughing-In</p>
<p>3 Construct a wood support under the floor according to the roughing-in dimensions.</p>	<p>4 Verify correct spout orientation before installing the base. The base has a notch on the cold supply side.</p>	<p>5 Use the base to mark the mounting holes on the wood support.</p>	<p>6 Using a 3/16" drill bit (provided), drill 1-1/2" (38 mm) deep holes at the marked locations. Use a masonry bit if drilling into concrete.</p>	<p>7 Install the base to the support with the screws and washers.</p>
<p>8 Apply sealant tape to the supply pipes. Thread the pipes into the base, with the cold supply on the notched side. Turn on the water and check for leaks.</p>	<p>9 Turn off the water and install the check valve to the diverter.</p>	<p>10 Finish the floor, leaving a 3-1/4" (83 mm) hole for the guard. Fit the finished floor between the MIN and MAX lines on the guard.</p>	<p>11 Trim the guard flush with the finished floor.</p>	<p>12 Remove the plugs from the base.</p>
<p>13 Install the faucet to the base with the screws and washers.</p>	<p>14 Install the check valve to the diverter. Install the handshower according to the manufacturer's installation instructions.</p>	<p>15 Remove the aerator. Run water to remove debris. Reinstall aerator.</p>		

Questions? Problems? For additional assistance, please contact
KALLISTA's Customer Service Department at 1-888-4-KALLISTA
(1-888-452-5547) or kallista.com.