



- Plus:**
- 1/2" nipple
 - Emery paper

<p>Record your model number.</p>	<p>⚠ CAUTION: Risk of product damage. To avoid plugging the showerhead spray outlets, use thread sealant tape on the shower arm threads. Do not use thread sealant compound (pipe dope).</p>	<p>NOTICE: Risk of personal injury. Choose an automatic compensating valve with the appropriate minimum flow rating, to assure your valve will provide safety at the lowest flow rates. For a showerhead with a maximum flow rate of 1.75 gal/min (6.6 l/min), use with an automatic compensating valve rated 1.4 gal/min (5.3 l/min) or less.</p>	<p>IMPORTANT INSTRUCTIONS CAUTION: Risk of scalding. KALLISTA low-flow showerheads/handshowers are designed for use with compatible KALLISTA valves. When installing a low-flow product to an existing showering system, verify compatibility before showering. Do not use this KALLISTA low-flow product with a shower valve that allows the water temperature to become too hot when other plumbing products are used.</p>	<p>IMPORTANT INSTRUCTIONS Before using your shower, verify your new showerhead/handshower is compatible with your shower valve (located behind the wall) by performing the following steps: <ul style="list-style-type: none"> • While standing outside the shower, turn on the shower valve. Do not step into the shower. • Adjust the water to your typical showering temperature. • Have someone flush the nearest toilet. • With your hand, carefully check the water temperature, from the showerhead/ handshower while the toilet is refilling. • If the water becomes significantly hotter, you will need to either replace the shower valve with a compatible KALLISTA valve or return your showerhead/handshower. </p>
<p>Important Information Observe all local codes. Shut off the water supply.</p>	<p>1 Apply sealant tape to a 1/2" nipple.</p>	<p>2 Install a male pipe nipple to extend 1/2" (25 mm) beyond the finished wall.</p>	<p>3 Loosen escutcheon setscrew.</p>	<p>4 Slide the escutcheon onto the shower arm.</p>
<p>5 Thread the shower arm onto the pipe nipple.</p>	<p>6 Tighten escutcheon setscrew.</p>	<p>7 Apply 100% silicone sealant to the escutcheon.</p>	<p>8 Remove the adapter with the provided 9 mm hex wrench.</p>	<p>9 Apply sealant tape to the adapter.</p>
<p>10 Install the adapter to the showerhead.</p>	<p>11 Install the showerhead to the shower arm.</p>	<p>12 Run water to flush.</p>		

Questions? Problems? For additional assistance, please contact
KALLISTA's Customer Service Department at 1-888-4-KALLISTA
(1-888-452-5547) or kallista.com.