













	1-3/16"	1/4" Strap Wrench	Sealant Tape	Plus: • Common woodworking and plumbing tools and materials.
Record your model number.	Important Information Do not use petroleum-based products in this faucet.	Important Information Follow all local plumbing and building codes.	1 Install 2x4 backing flush with the studs, at the installation location.	2 Install a 1/2" NPT supply pipe to extend no more than 1/2" (13 mm) beyond the wall.
			These surfaces must be flush.	1/2" (13 mm) Max
3 Secure the supply pipe to the 2x4 backing.	4 Complete the finished wall. Provide a 1-3/16" (30 mm) hole around the supply pipe.	5 Slide the mounting plate on the faucet shank. Tighten the setscrew into the groove.	6 Thread the shank to the supply pipe so the mounting plate is flush.	Position the mounting plate with the setscrew hole facing down.  Mark the four screw hole locations.
Secure here.	Ø 1-3/16" (30 mm)			Setscrew
8 Remove the faucet from the supply pipe. Remove the mounting plate from the shank.	9 Drill four 1/4" holes at the marked locations.	10 Apply thread sealant to the supply pipe.	11 Position the mounting plate over the holes with the setscrew hole facing down. Secure with the four screws.	12 Slide the escutcheon onto the shank.
			Setscrew	
13 Use a strap wrench to secure the faucet to the supply pipe.	14 Align the faucet groove with the setscrew hole in the mounting plate. Tighten the setscrew.	15 Slide the escutcheon against the wall with the setscrew down. Tighten the setscrew.	<b>16</b> Turn both handles fully clockwise to the off position.	<b>17</b> Turn on the water supply and check for leaks.

18 Remove the aerator and open both handles to flush debris from	<b>19</b> Turn off the water and rethe aerator.	reinstall		
the faucet.	the aerator.			
Questions? Problems? For additional assistance, please contact KALLISTA's Customer Service Department at 1-888-4-KALLISTA (1-888-452-5547) or kallista.com.				

1395073-2-**A** © 2019 KALLISTA