



Record your model number: _____
1430520-W2

WARNING: Risk of scalding. High water temperature can cause severe burns. Set the valve water temperature at or below 120°F (49°C). Refer to the temperature adjustment instructions for the valve.

CAUTION: Risk of product damage and personal injury. Keep the product away from a heater.

Follow all local plumbing and building codes.

1A. 10 mm Socket

1B. Sealant Tape

1C. 8 mm Hex Wrench

1D. 8 mm Drill Bit

1E. 2x4s

2A. For Concrete Ceilings: Cut away the concrete and/or brick 2-3/4" (70 mm) to 4-3/8" (111 mm) above the finished ceiling.

2B. For Wood Backing: Install 2x4 wood support between the ceiling joists 2-3/4" (70 mm) to 4-1/2" (114 mm) above the finished ceiling.

4A. Installation to Concrete: Use a 8 mm drill bit.

4B. Installation to Wood Backing: Use the provided 3/16" drill bit.

5A. Installation to Concrete: Use the provided concrete expansion anchors.

5B. Installation to Wood Backing: Use the provided lag screws.

7A. Install G1/2 supply pipes.

8A. Flush hot and cold water for 1 minute to remove any debris.

10A. Install the finished ceiling.

11A. Using an 8 mm hex wrench, secure the pipe assemblies to the mounting block.

14A. Loosely secure the escutcheon. Do not scratch the arm.

15A. Temporarily use the clip to align the adapters.

16A. Install the rainhead (not included). Slide the arm down to the rainhead.

Need help? Contact our Customer Service.

• Email: technicalsupport@kohler.co.uk

• 0800 001 4466

This product is covered under the **KOHLER® Showerheads, Shower Fittings, Bathroom Accessories, and Wastes Two-Year Limited Guarantee.** For a hardcopy of guarantee terms, contact Customer Service.



