





Record your model number:

Follow all local plumbing and building codes.

1A. 6 mm Drill Bit

2A. 1219 mm Minimum

5A. Drill 6 mm holes at the marked locations.

 $8A.\ Loosely\ thread\ both\ setscrews\ into\ the\ slidebar.$

Need help? Contact our Customer Service.

- Email: technicalsupport@kohler.co.uk
- 0800 001 4466

This product is covered under the **KOHLER® Showerheads**, **Shower Fittings**, **Bathroom Accessories**, **and Wastes Two-Year Limited Guarantee**.
For a hardcopy of guarantee terms, contact Customer Service.



