

NEW VERDERA 新维乐

INSTALLATION INSTRUCTIONS 安装说明书 MIRRORED CABINET 镜柜 K-78202T-L/K-78202T-R/K-78282T

BEFORE YOU BEGIN

- Please read these instructions carefully to familiarize yourself with the required tools, materials, and installation sequences. Follow the sections that pertain to your particular installation. This will help you avoid costly mistakes. In addition to proper installation, read all operating and safety instructions.
- All information in these instructions is based upon the latest product information available at the time of publication.
 Kohler China. reserves the right to make changes in product characteristics, packaging, or availability at any time without notice.
- These instructions contain important care, cleaning, and warranty information-please leave instructions for the consumer.
- Before installation carefully inspect the new fixture for any signs of damage.
- This product complies with GB/T10357.4-2013, GB/T10357.5-2013 and GB24977-2010.
- WARNING: Risk of injury or product damage. Be careful when opening the door to avoid pinching fingers.
- WARNING: Don't use acidic or alkalic cleaners or alcohol to clean the surface. Use a dampened cloth to clean
- **CAUTION: Risk of electric shock.** Electrical wiring may need to be relocated.
- CAUTION: Risk of property damage. Use anchors (not provided) rated for the loaded weight of this product. Refer to the anchor manufacturer's instructions.
- Important Information: This cabinet is designed for either right or left door swing. Check the wall cavity for obstructions.

Grounding Instructions

- This product should be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.
- **WARNING: Risk of electric shock.** Improper use of the grounding plug can result in a risk of electric shock.
- If repair or replacement of the cord is necessary, do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire.
- Check with a qualified electrician or service personnel if the grounding instructions are not completely understood, or if in doubt as to whether the product is properly grounded.
- This product is factory equipped with a specific electric cord.
 If the product must be reconnected for use on a different
 type of electric circuit, the connection should be made by
 qualified service personnel.

安装之前

- 请仔细详阅本指引,以便熟悉所需工具、物料及安装程序。请遵照适用的章节来安装本产品,以免安装失当导致不必要的损失。除了有关正确的安装方法之外,还务请详阅所有操作及安全指引。
- 本指引所载之一切资料,均以印刷时所有之最新产品情况为基础,科勒中国保留权利随时更改产品特性、包装或供应情况,恕不另行通知。
- 本指引也包含了有关保养、清洁及担保等重要资料-请交予 用户保存。
- 安装之前,仔细检查产品是否有损伤。
- 本产品符合GB/T10357.4-2013、GB/T10357.5-2013和GB24977-2010。
- 警告:可能有人员伤害或者产品损坏的危险。为防止门 左右移动时夹到手指,请注意推门的位置。
- ◆ 警告:表面不能用含酸或碱性的清洁剂以及酒精清洁,请用潮布清洁。
- 警告: 触电风险。可能需要重新布线。
- ♠ 警告: 财产损失风险。请使用可承载本产品重量的膨胀螺栓(不随货提供)。请参考螺栓制造商的产品说明。
- **重要信息:** 本镜柜有适用于左右开门安装的型号, 请注意区别。请检查墙体内壁空间是否存在障碍物。


接地须知

- 本产品须接地。在电源短路时,接地能够为电流提供一条 散逸通路,从而减少产生电击的危险。
 - ↑ 危险: 有电击的危险。接地使用不当可引起电击危险。
- 如果必须修理或更换电源线,不得将接地线连接到任何一只扁平端子上。接地线是外表面为绿色、带或不带黄色条纹的绝缘线。
- 如果没能完全理解"接地须知",或是担心产品是否正确接地,请向具有资质的电工或维修人员查对。
- 该产品出厂即配有专用的电源线。如果必须要重新连接该产品,以便在不同类型的电路中使用,则必须由具有资质的维修人员来完成这项工作。

ZHONGSHAN KOHLER SHOWER CO., LTD. NO13-1, XINGYE ROAD, ZHONGSHAN TORCH DEVELOPMENT ZONE, ZHONGSHAN, GUANGDONG, CHINA POST CODE: 528437 中山科勒卫浴有限公司 广东省中山市中山火炬开发区兴业路13-1号 邮编: 528437


TOOLS REQUIRED

所需工具



PARTS SUPPLIED


随附零件




ROUGHING-IN

尺寸图

Reference Value UNIT: mm 参考值 单位: 毫米 K-78282T K-78202T-L/K-78202T-R 866





Kohler reserves the right to change marked dimensions without prior notice. 科勒公司保留随时变更图中标示尺寸的权利,无需另行通知。


ELECTRICAL PARTS LIST

Item	Electrical Function	Type Description	Fixate Place
1	Defogger	Input: DC12V, Pmax=15W	Back of Outer-mirror
2	Lighting	Input: DC12V, Pmax=15W, LED 3000K	Inside the Door

序号	电器功能	规格描述	安装位置
1	防雾膜	Input: DC12V, Pmax=15W	贴外镜背面
2	灯具	Input: DC12V, Pmax=15W, LED 3000K	门体内部

安装

Surface-Mount Installation





挂墙式安装

Mark the mounting bar position (centered as desired). Mark stud locations. 标记安装支架的位置(根据所需确定中心点)。标记螺钉的位置。


Mark hole locations on the wall. Drill holes. Insert anchors where needed.

在墙上标记安装孔的位置。钻孔。在所需处插入入墙胶粒。






Rotate the cabinet for right or left door swing with KOHLER logo on the bottom of the outside mirror. 根据左右开门安装,KOHLER标志在外镜底部。





Lift the cabinet onto the mounting bar. Ensure the hooks engage the bar. 将镜柜抬至安装支架处。确保钩子与支架正确连接。





If needed, insert anchors into the wall. Secure the clips with round-headed long screws.


若有需要,将入墙胶粒插入墙面。用圆头的长螺钉固定搭扣



















Installation and Adjustment of Accessories

Install the clips. Insert the shelves between the clips. 安装夹子。将层板插入夹子中。 STEP 1

配件安装及调节








Installation of Side Mirror (Note: Not necessory for recess-mount installation.)

Find the two bracket locations on each side of the cabinet. 在镜柜两侧找出支架位置。

侧镜安装(注:入墙式安装不需要装侧镜。)








STEP

Power line connection

电源线接入



Line outlet of cabinet

镜柜出线位置图示

