



1314915-2-**A** 

Connect the supply hoses to the supply stops.	<b>25</b> Turn on the water supplies. Check for leaks.	<b>26</b> Run water to flush debris.	<b>27</b> Turn off the water. Install the aerator.
	supply stops.	Supply stops. Check for leaks.	supply stops. Check for leaks.

Questions? Problems? For additional assistance, please contact KALLISTA's Customer Service Department at 1-888-4-KALLISTA (1-888-452-5547) or kallista.com.	