



Corbelle® Comfort Height® Toilet With
Revolution 360® Swirling Flush
and ContinuousClean Technology
K-5709-0

ContinuousClean and Revolution 360® Swirl Flush Technologies

FERGUSON[®]
Bath, Kitchen & Lighting Gallery

THE BOLD LOOK
OF **KOHLER**[®]

ContinuousClean and Revolution 360® Swirl Flush Technology

Our cleanest flush. Yet.

ContinuousClean technology automatically fights grime, germs, and stains with every flush to help your bowl stay clean longer, so you can spend less time cleaning. ContinuousClean toilets are powered by the AquaPiston® canister flush engine and Revolution 360 swirl flush technology that sends 360-degrees of water through the bowl for complete coverage that leaves nothing behind. These toilets also offer the CleanCoat™ surface treatment which prevents bacteria, mildew, and mineral deposits from sticking to the bowl. Together these technologies give you our cleanest flush yet.



Revolution 360 Swirl Flush Technology

This innovative flushing technology sends 360 degrees of water through the bowl for complete coverage that leaves nothing behind.



ContinuousClean Self-Cleaning Technology

ContinuousClean technology with CleanCoat surface treatment keeps the bowl clean 5x longer,* and ContinuousClean technology is available in a single- or two-tablet system—bringing you ContinuousClean technology on even more toilets.



AquaPiston Flush Engine

The driving force behind Revolution 360 and ContinuousClean is the AquaPiston canister flush engine. AquaPiston packs a powerful punch to eliminate clogs.

SKU	Description	Revolution 360	CleanCoat	Tank SKU	Bowl SKU	Rough-In	Water Usage	Bowl Shape
K-5709	Corbelle Comfort Height toilet with ContinuousClean XT	•	•	K-5711	K-4144	10", 12", or 14"	1.28 gpf 	Elongated
K-31644	Cimarron Comfort Height toilet with ContinuousClean ST	•	•	K-31618	K-31589	12"	1.28 gpf 	Round-front
K-31624	Cimarron Comfort Height toilet with ContinuousClean ST	•	•	K-31618	K-31588	12"	1.28 gpf 	Elongated
K-90097	Irvine Comfort Height toilet with ContinuousClean XT	•	•	K-90098	K-20485	10", 12", or 14"	1.28 gpf 	Elongated

*KOHLER toilet with ContinuousClean compared to KOHLER toilet without ContinuousClean and based on consumer perception study and bacterial counts.



WaterSense®-labeled toilets use at least 20% less water than standard 1.6-gallon toilets while still meeting strict flushing performance guidelines.

ContinuousClean Technology Quick Start Guide


ContinuousClean technology automatically dispenses cleaning solution to keep the bowl clean longer.

ContinuousClean XT

This two-tablet system has three settings, and is designed to automatically dispense cleaning solution for up to one year with standard use.

- 1 First remove the lid of the toilet.
Then get started by installing two AAA batteries (included).

(Batteries are not required for the ContinuousClean system to work, only for the indicator light.)



The batteries power the blue ContinuousClean indicator light that lets you know the system is working, and it will alert you (with a red light) when the cleaning agent is running low.

- 2 Unlatch and remove the cover of the reservoir system.




- 3 Insert two puck-style cleaning tablets.
Be careful not to touch the tablets.



Liquid or powder cleaners won't work in this system. Please follow the handling instructions provided on your preferred tablet packaging, and DO NOT handle the tablets directly.

Note: During toilet installation, Kohler recommends inserting toilet cleaning tablets prior to turning on the water to the toilet.

- 4 Set the dial to your preferred setting.

 This is the recommended setting that evenly dispenses the cleaning agent with every flush.

+ If you want more cleaning agent added to your flush, choose this setting. This setting may result in a stronger scent from the cleaning agent when flushing.

- If you want less cleaning agent added to your flush, choose this setting. Rest assured, you will still be fighting germs with every flush; however, with a lower setting of cleaning solution you may need to clean the bowl sooner than you would using the recommended setting.



- 5 Replace the reservoir cover and lock into place.



- 6 Place the lid back on the toilet.
Then check that the indicator light is working when you flush.

You should see a blue pulse (*one second in duration*), which indicates the system is working properly and cleaning solution is being delivered with each flush.



ContinuousClean ST

This single-tablet system is mechanically operated, no batteries required. Simply add a single cleaning tablet to automatically dispense cleaning solution for up to six months.

- 1 First remove the lid of the toilet.



- 2 Unlatch and remove the cover of the reservoir system.



- 3 Insert single puck-style cleaning tablet.
Be careful not to touch the tablet.



Liquid or powder cleaners won't work in this system. Please follow the handling instructions provided on your preferred tablet packaging, and DO NOT handle the tablets directly.

Note: During toilet installation, Kohler recommends inserting toilet cleaning tablets prior to turning on the water to the toilet.


- 4 Replace the reservoir cover and lock into place.



- 5 Place the lid back on the toilet.



- 6 The toilet will now begin dispensing cleaning solution with every flush.



[KOHLER.com/ContinuousClean](https://www.kohler.com/ContinuousClean)
[KOHLER.com/Revolution360](https://www.kohler.com/Revolution360)

 **FERGUSON**[®]
Bath, Kitchen & Lighting Gallery

THE BOLD LOOK
OF **KOHLER**[®]

Form 21-3023-1121
© 2021 Kohler Co.
Kohler, Wisconsin 53044
Printed in U.S.A.
1-800-4-KOHLER
(1-800-456-4537)