

no
touch
flush™



Touchless Toilet Flush Kit
K-1954-0

KOHLER touchless™
Toilet Flush Kit

THE BOLD LOOK
OF **KOHLER**®

Upgrade to the no-touch flush for your home.

KOHLER. touchless.

Nothing to touch means fewer germs to pick up or leave behind. The KOHLER® Touchless toilet flush kit turns a standard toilet into a touchless toilet. Simply hold your hand over the sensor to flush—no touching required. Works with most canister (A) and flapper (B) toilets.

Fits Most Toilets

Works with canister and flapper toilets

Easy to Use

Simply hold your hand over the sensor to activate

Hygienic




Going touchless means fewer germs to pick up or leave behind

No Wiring Needed

Powered by 4 AA batteries (included)

Easy Installation

Kit is quick and simple to install



SKU	Description
K-1954-0	Touchless Toilet Flush Kit*

*Hole cover in white included. Other colors are available.
Not compatible with dual-flush, top-mount flush, pressure-assist or ballcock valve toilets.

THE BOLD LOOK
OF **KOHLER.**

KOHLER.com/TouchlessToilet

Form 14-1628-0414
© 2014 Kohler Co.
Kohler, Wisconsin 53044
Printed in U.S.A.
1-800-4-KOHLER
(1-800-456-4537)