

# 25" undermount single-bowl kitchen sink K-5872-5UA1

### **Features**

- 28" minimum base cabinet width
- Single bowl
- 9" (229 mm) depth provides generous workspace
- Five oversized faucet holes
- Oversized holes allow for easy installation of faucets and accessories
- Bowl slopes toward drain to minimize water pooling
- Offset drain increases workspace in the sink and storage space underneath
- Small size fits compact spaces
- Sink drain with strainer sold separately

## Material

KOHLER® enameled cast iron

# Installation

- Undermount
- Undermount installation kit not included

# **Recommended Products/Accessories**

K-6238 Sink Rack

K-8801 Sink drain and strainer with tailpiece

K-8799 Sink drain and strainer basket

K-6194 Utility Rack With Soaking Cup

K-6239 Colander with Cutting Board

K-6246 Maple hardwood cutting board

K-11352 Disposal Flange with Stopper

K-9000 P-Trap

1411886 Undermount sink kit 23"

K-23726 Drain treatment

K-23725 Cast iron cleaner

# **Included Components**

K-6238 Sink Rack



# Codes/Standards

ASME A112.19.1/CSA B45.2 IAPMO Certification

# KOHLER® Enameled Cast Iron Kitchen and Bathroom Sink Lifetime Limited Warranty

See website for detailed warranty information.

# **Available Colors/Finishes**

Color tiles intended for reference only.


Color	Code	Description
	0	White
	FF	Sea Salt™
	96	Biscuit
	NY	Dune
	95	Ice™ Grey
	58	Thunder™ Grey
	7	Black Black™
	TRF	Truffle







# **KOHLER**®

# Riverby® 25" undermount single-bowl kitchen sink K-5872-5UA1







### **Technical Information**

All product dimensions are nominal.

Bowl configuration: Single

Min. base cabinet 28" (711 mm)

width:

Bowl area (Only): Length: 22-1/4" (565 mm)

5

Width: 15-13/16" (402 mm)

Bowl depth: 9" (229 mm)

Number of deck

holes:

Faucet hole(s): 2-3/8" (60 mm)

Drain hole: 3-7/8" (98 mm)

Template: 1172565-7, required, included

## **Notes**

Install this product according to the installation instructions.

NOTICE: Countertop manufacturer or cutter must use the cut-out template provided with the product, or a current one provided by Kohler Co. (call 1-800-4-KOHLER). Kohler Co. is not responsible for cutout errors when the incorrect cut-out template is used.

IMPORTANT! Use of the colander, wood cutting board, and utility rack requires the "reveal" cutout option on the cutout template.

