


KALLISTA®

Installation Guide



Plus:
• 3/16" Masonry Bit
(For Concrete Installation)

<p>Record your model number.</p>	<p>⚠ CAUTION: Risk of personal injury. Do not use this product as a grab or support bar when entering or exiting the bath. The product is not designed to support weight.</p>	<p>NOTICE: Adequate floor support is required. Standard 2x6 lumber is NOT sufficient for this application. NOTE: Concrete can be used as the floor support. Follow all local plumbing and building codes.</p>	<p>1 Roughing-In</p>	<p>2 Roughing-In</p>
<p>3 Construct a wood support under the floor according to the roughing-in dimensions.</p>	<p>4 Use the base to mark the mounting holes on the wood support.</p>	<p>5 Using a 3/16" drill bit (provided), drill 1-1/2" (38 mm) deep holes at the marked locations. Use a masonry bit if drilling into concrete.</p>	<p>6 Secure the base to the support with the screws and washers.</p>	<p>7 Apply sealant tape to the supply pipes and thread into the base. The cold supply goes over the notch.</p>
<p>8 Insert the plug into the base. Turn on the water and check for leaks.</p>	<p>9 Turn off the water and secure the guard onto the base.</p>	<p>10 Finish the floor, leaving a 3" (76 mm) diameter hole for the guard.</p>	<p>11 Cut the guard flush with the finished floor.</p>	<p>12 Remove the plug from the base.</p>
<p>13 Secure the faucet to the base with the screws and washers.</p>	<p>14 Install the check valve and handshower hose to the diverter.</p>	<p>15 Turn on the water to flush debris from the hose.</p>	<p>16 Install the handshower to the hose.</p>	<p>17 Remove the aerator. Run water to remove debris. Reinstall aerator.</p>

Questions? Problems? For additional assistance, please contact
KALLISTA's Customer Service Department at 1-888-4-KALLISTA
(1-888-452-5547) or kallista.com.