



<p><b>Record your model number.</b></p>	<p><b>⚠ CAUTION: Risk of personal injury.</b> Do not use this product as a grab or support bar when entering or exiting the bath. The product is not designed to support weight.</p>	<p><b>NOTICE:</b> Adequate floor support is required. Standard 2x6 lumber is NOT sufficient for this application. <b>NOTE:</b> Concrete can be used as the floor support. Observe all local plumbing and building codes.</p>	<p><b>1 Roughing-In</b></p>	<p><b>2 Roughing-In</b></p>
<p><b>3</b> Construct a wood support under the floor according to the roughing-in dimensions.</p>	<p><b>4</b> Use the base to mark the mounting holes on the wood support.</p>	<p><b>5</b> Using a 3/16" drill bit (provided), drill 1-1/2" (38 mm) deep holes at the marked locations. Use a masonry bit if drilling into concrete.</p>	<p><b>6</b> Secure the base to the support with the screws and washers.</p>	<p><b>7</b> Apply sealant tape to the supply pipes and thread into the base. The cold supply goes over the notch.</p>
<p><b>8</b> Insert the plug into the base. Turn on the water and check for leaks.</p>	<p><b>9</b> Turn off the water and secure the guard onto the base.</p>	<p><b>10</b> Finish the floor, leaving a 3" (76 mm) diameter hole for the guard.</p>	<p><b>11</b> Cut the guard flush with the finished floor.</p>	<p><b>12</b> Remove the plug from the base.</p>
<p><b>13</b> Secure the faucet to the base with the screws and washers.</p>	<p><b>14</b> Install the check valve and handshower hose to the diverter.</p>	<p><b>15</b> Divert water to the hose and turn on water to remove debris from the hose.</p>	<p><b>16</b> Install the handshower to the hose.</p>	<p><b>17</b> Remove the aerator and divert water back to the spout. Run water to remove debris. Reinstall aerator.</p>

Questions? Problems? For additional assistance, please contact  
KALLISTA's Customer Service Department at 1-888-4-KALLISTA  
(1-888-452-5547) or [kallista.com](http://kallista.com).