

#### **INSTALLATION**

#### General

- Make sure that the BTW WC is installed by a competent installer
- Before installation carefully inspect the new item for any signs of damage.

## Install the Plumbing

 Make sure that the services are installed to the dimensions for the particular BTW pan. The recommended cistern is Kohler Part No. 6285W-NF-6L concealed cistern.

**Note!** To comply with UK water regulations, the water level in the Kohler concealed cistern must be set to the 6L line in the cistern.

**Caution!** Make sure a watertight seal exists on all WC drain connections.

**Caution!** Provide access to the in built cistern for future plumbing maintenance.


- **2.** Apply a layer of grease to the inside of the inlet and outlet pipe holes.
- The inlet and outlet pipes must be cut to the correct length in accordance with the cistern manufacturer's instructions.

### Install the Toilet (method 1)

 Position the WC and mark through the position of the fixing holes in the base of the WC pan.


**Caution!** Make sure that you avoid hidden cables and pipes when drilling holes in the floor.

- 2. Remove the WC and drill the holes with an 8 mm drill.
- 3. Connect the WC to the waste outlet and flush pipe.




4. Secure the WC in position with the floor plugs and the bolts. Fit the plastic cover caps over the heads of the bolts.


# Install the Toilet (method 2)




 Place the template on the floor, align the back edge to the wall and secure the template in position. Drill the fixing holes with an 8 mm drill.



- 2. Fit the clamps or bracket to the floor and secure in positon with the floor plugs, washers and the bolts.
- 3. Position the WC over the floor fixings and connect the waste outlet pipe and the waste pipe.



**4.** Secure the WC to the clamps with the plastic sleeves and the screws. Fit the plastic cover caps over the heads of the screws.



Secure the WC to the bracket with the bolts and the washers. Fit the concealing caps to cover the bolt heads.

#### Finish the Installation

- 1. Ensure that all the connections are tight.
- 2. Turn on the water supply and check for any leaks.
- 3. Flush the toilet to check for correct operation.

Tel: 0870 8505551, Fax: 0870 8505552, Website: www.kohleruk.com